

SUPPORT

Models supported include PDS-811 and PDS-821

WARRANTY

All products manufactured by ICP DAS are warranted against defective materials for a period of one year from the date of delivery to the original purchaser.

WARNING

ICP DAS assumes no liability for damages consequent to the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, nor for any infringements of patents or other rights of third parties resulting from its use.

COPYRIGHT

Copyright © 2018 by ICP DAS. All rights are reserved.

TRADEMARKS

Names are used for identification purposes only and may be registered trademarks of their respective companies.

CONTACT Us

If you have any questions, please feel free to contact us. We will respond within 2 working days.

Email: service@icpdas.com ; service.icpdas@gmail.com

PDS-8x1 Series

Firmware Update via 7188XW.exe

Version: 1.0/ Updated: Sep. 2018

Ch. 1. Setting up the PDS-8x1

Ch. 2. Firmware Update Procedure

Ch. 3. Additional Information



ICP DAS CO., LTD.

Website: <http://www.icpdas.com>

1. Setting up the PDS-8x1


Before updating the firmware, please ensure that the PDS-8x1 module is connected with your host computer. Refer to the following steps for the details.

Step 1: **Switch off** the Power to the PDS-8x1 module.

Step 2: Connect the DB-9 connector of CA-0910 download cable to your host computer.


Step 3: Wire the CA-0910 to PDS-8x1 module, as follows:

- 3-1: Connect the **CA-0910.TX** with **PDS.8x1.TxD**
- 3-2: Connect the **CA-0910.RX** with **PDS.8x1.RxD**
- 3-3: Connect the **CA-0910.GND** with **PDS.8x1.GND**



Step 4: Set the “Init/Run Switch” on the PDS-8x1 module to the in “Init ” position to initiate the update.

Step 5: **Switch on** the Power to the PDS-8x1 module.



2. Firmware Update Procedure

Step 1: Download the Firmware File of PDS-8x1 module and then decompress it to a temp folder, for example PDS800fw.



[Download the Firmware File.](#)

The PDS-8x1 firmware and autoexec.bat files are compressed in Zip format. You can decompress the zip file by 7-Zip, WinZip, WinRAR... utilities.

Step 2: Modify COM Port number in 7188xw.ini file, depend on your PC COM Port that connect to PDS-8x1.

For Example (first parameter of the line 1 in the 7188xw.ini)

COM1 ==> C1 B115200 P0 D8 S1


COM2 ==> C2 B115200 P0 D8 S1

1 Double Click

2
C: COM Port (e.g. C7) → Modify this item.
B: Baud Rate (e.g. B115200)
P: Parity (e.g. P0)
D: Data Bits (e.g. D8)
S: Stop Bits (e.g. S1)

3
Select the “Save” item from the “File” menu to save the new configuration.

Step 3: Double click the **PDS-800.bat** for starting update.



Step 4: You are now ready to update the firmware. The **PDS-800.bat** file will auto run the **7188XW.exe** utility program and shows the progress of the update.

Step 5: The **7188XW.exe** utility program will then upload the **firmware** and **autoexec.bat** files into PDS-8x1 module automatically. If the update cannot proceed, please refer to **note1 (Page 8)**.

```
C:\Users\RD1-Tammy\Desktop\PDS-8x1\Firmware\PDS800fw_180222\PDS800fw
C:\Users\RD1-Tammy\Desktop\PDS-8x1\Firmware\PDS800fw_180222\PDS800fw>7188xw /RPDS-800.ini
7188x for WIN32 version 1.36 (2008/02/26)[By ICP DAS, Tim Tsai.]
[Begin Key Thread...]Current set: Use COM7 115200,N,8,1
AutoRun:
Autodownload files: None
Current work directory="C:\Users\RD1-Tammy\Desktop\PDS-8x1\Firmware\PDS800fw_180222\PDS800fw"
original baudrate = 1200!
now baudrate = 115200!
del /y
Total File number is 2, do you really want to delete(y/n)?

P824A_UDP>LOAD
File will save to 8000:0000
StartAddr-->7000:FFFF
Press ALT_E to download file!
Load file:vp8_3301.exe[crc=EF38,0000]
Send file info. total 365 blocks
Block 104
```


Starting update

Step 6: The Firmware update completed when display **[End file xxx]** message. Then click the **"X"** icon on the right-top corner of the windows to close it.


```
7188XW 1.36 [COM7:115200,N,8,1],FC=0,CTS=0, DIR=C:\Users\RD1-Tammy\Desktop\PDS-8x1\Firmware\PDS800fw_180222\PDS800fw
Transfer time is: 17.625000 seconds
P824A_UDP>LOAD
File will save to 96CF:0004
StartAddr-->9000:6CF3
Press ALT_E to download file!
Load file:autoexec.bat[crc=E6FB,0000]
Send file info. total 1 blocks
Block 1
Transfer time is: 0.078000 seconds
P824A_UDP>type autoexec.bat
runexe
P824A_UDP>autoexec.bat
config=RESET
Vcom3301>com 0=9600 8 N 1
COM 1=9600,8,N,1. connect=0
Vcom3301>original baudrate = 115200!
now baudrate = 9600!
Current baud rate is 9600
original baudrate = 9600!
now baudrate = 115200!
Current baud rate is 115200
[End file 272]
```

Step 7: Set the **"Init/Run Switch"** on the PDS-8x1 module to the in **"Run"** position.

Step 8: **Switch off** the Power to the PDS-8x1 module and then switch it back on again to reboot the module to **"Run"** operation.




Step 9: Connect both the PDS-8x1 module and your computer to the same sub network or the same Ethernet Switch.




Step 10: Install the VxComm Utility on your Host PC, and then run the Utility to search for any PDS-8x1 module connected to the network.



[Download the VxComm Utility.](#)



Step 11: Configure the correct network settings for the required PDS-8x1 module.




Please refer to “Chapter 3-Configuring Network Settings” in the PDS-8x1 Quick Start Guide. If the IP address settings do not work correctly, please refer to **note2 (Page 8)**.



[Download the Quick Start Guide.](#)


Step 12: Click the name of the PDS-8x1 module.

Step 13: Click the “Web” button.



Step 14: Log in to the web configuration pages for the PDS-8x1.

Step 15: Verify that the firmware version and date details are correct.



3. Additional Information

Notes:

 **Note 1:** Make sure the 7188XW.exe and autoexec.bat program files exist on the same folder. If not, update firmware can't be successful. [back](#)

 **Note 2:** If the IP address settings do not work correctly (e.g. there is no response to a ping command), please contact your network administrator to obtain a valid IP address for the PDS-8x1 module. [back](#)

 **Note 3:** 7-Zip—Free Archiving (Compress and Decompress) Utility
7-Zip is a free archiving utility, you can get it from the following web:
<http://www.7-zip.org/>