

Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	1 / 12

## How to Allow the SCADA/HMI to Access Win-GRAF Variables?


This FAQ-008 provides a Win-GRAF project called “faq008” which includes two LD programs. One is used to get/set the PAC system time (i.e., the “PAC\_Time” program) and the other is used to create a blinking function (i.e., the “LD1” program). The user can refer [Win-GRAF Getting Started](#) – Chapter 2 (Demo01) to know more details.

Moreover, this paper describes how to set up Win-GRAF variables as public data by enabling the Win-GRAF PAC as the Modbus TCP slave or the Modbus RTU slave so that the SCADA/HMI software (e.g., “InduSoft”) can access Win-GRAF PAC’s data. Follow the instructions below to set up.

**Note:** The following setting has been completed in the “faq008” project. The user can run the Win-GRAF and then click File > Add Existing Project > From Zip in the menu bar to restore this project (or refer the FAQ-003).


### 1.1. To Enable the Win-GRAF PAC as a Modbus TCP Slave

1. Click the “Open Fieldbus Configuration” tool button to open the “IO Drivers” window.




Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	2 / 12


- Click the “Insert Configuration” button on the left side of the “IO Drivers” window and then select the “MODBUS Slave” and click “OK” to enable a Modbus TCP Slave.



- Click the “Insert Master/Port” button on the left side to set the “Slave number” (In this case, the value is “1”), and click the “OK” button.




- Click the “Insert Slave/Data Block” button on the left side to open the “MODBUS Slave Request” window.



Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	3 / 12

5. Enter a simple note in the “Description” field and then click the "Input Registers" option.



For Modbus Master to Read data:


Options	Data types
Input Bits	BOOL
<b>Input Registers</b>	BYTE, INT, DINT, REAL, etc.

For Modbus Master to Write data:

Options	Data types
Coil Bits	BOOL
Holding Registers	BYTE, INT, DINT, REAL, etc.

6. As the screenshot above, it is recommended to set the “Base address” to “1” and the “Nb items” refers to how much variable data can be provided by one “data block”. If the data address requested from the Modbus Master (e.g., the SCADA software) is greater than this value (in this example, the value is “2000”), the Modbus Slave (i.e., Win-GRAF PAC) will not respond.

7. Mouse drags all the needed variables (e.g., “PAC\_xxx”, data type: “DINT”) one-by-one from the Variables area and then drop it to the “Symbol” field.



Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	4 / 12

8. Mouse double-click the “Offset” field and fill in a value, then press “Enter” key to finish the setting.

- Note:** (1) The “Offset” value starts at “0” and the Modbus address of variable is equal to this value plus 1 (Base address).  
 (2) If using a 32-bits (or more than 32-bits) data type (e.g., “DINT”), it requires two Modbus addresses, as the table below, the “Offset” values are “0”, “2”, “4”, “6”, etc.

Symbol	Offset	Mask	Storage
PAC_Year	0	FFFF	Default
PAC_Month	2	FFFF	Default
PAC_Day	4	FFFF	Default
PAC_Hour	6	FFFF	Default
PAC_Minute	8	FFFF	Default
PAC_Second	0	FFFF	Default
PAC_WeekDay	0	FFFF	Default

**Tips:**

Mouse click the “Offset” field and press the keyboard “Ctrl+A” to select all items, and then click the “Iterate Property” button at the left side to open the settings window.


Keep the “Name” setting, enter “0” into “From” field and enter “2” into “By” field, then click “OK”.

(If the “Name” is set to “%%”, it will show “00, 22, 44, 66, 88, 1010, 1212” in this example. The user can modify it depends on the needed settings and then check the value in the “Results” area.)


Symbol	Offset	Mask	Storage
PAC_Year	0	FFFF	Default
PAC_Month	2	FFFF	Default
PAC_Day	4	FFFF	Default
PAC_Hour	6	FFFF	Default
PAC_Minute	8	FFFF	Default
PAC_Second	10	FFFF	Default
PAC_WeekDay	12	FFFF	Default

Classification	Win-GRAF English FAQ-008							
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	5 / 12	

9. Click “Storage” to select entire columns and then press “Enter” key to display a drop-down menu. Then, select “DWORD (Low – High)” and press “Enter” key to complete the setting. (If using a 16-bits or below, it is no need to set the “Storage” item.)




To expand this “Data Block” and you can see the Modbus addresses of all variables. It equals to the “Offset” value plus “1” (Base address).



10. Then, we need to add the second “Data Block” for the Modbus Master to read the Boolean data. This configure way is similar to the step 4 to 8:

Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	6 / 12


- (1) Click the “Server - ...” item and click the “Insert Slave/Data Block” button at the left side to open the settings window.
- (2) In the “MODBUS Slave Request” window, enter a simple note and select the “Input-bits” option, then set “Base address” to “1” and set “Nb items” to “2000”.



**For the Modbus Master to Read data:**

Option	Data Type
<b>Input Bits</b>	BOOL
Input Registers	BYTE, INT, DWORD, REAL, LINT, etc.


- (3) Mouse drags the Boolean variables (i.e., “LED1”, “LED2”; data type: BOOL) one-by-one and drop them to the “Symbol” area, and then set the “Offset” to “0” and to “1”.






You have completed the settings for the Modbus Slave. Finally, follow the way below to re-compile the program and download it to the Win-GRAF PAC.

Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	7 / 12

11. Click “Project” > “Build All Projects” from the menu bar to compile this program again (as the figure below). If a message informs you, “No error detected” that means this process is successful.



12. Mouse right-click the project name (i.e., “Demo01”) and select the “Communication Parameters...” to set the PAC IP (e.g., “192.168.71.19:502”) and then click the menu bar “Project” > “On Line” (or ) to establish a connection and download this project to the Win-GRAF PAC.



After completing all the steps, the HMI/SCADA software can access to all the Win-GRAF variables listed above via Modbus TCP protocol.


Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	8 / 12

## 1.2. To Enable the Win-GRAF PAC as a Modbus RTU Slave


Before doing this, you must complete all the content that described in [Section 1.1](#) to open the Modbus Slave data. The way to enable the Win-GRAF PAC as the Modbus RTU Slave is to add the “MBSLAVERTU” or the “MBSLAVERTUEX” function block in the program. To begin, follow these steps:

### 1.2.1. Add the “MBSLAVERTU” function block

1. In the “LD1” window, mouse click the place where you want to add this function block and then click the “Insert FB..” button on the left side of the window.




2. Double-click on this function block and select the name “MBSLAVERTU”, then click “OK”.







Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	9 / 12




- In the "MBSLAVERTU" function block, mouse double-click the left side of the "PORT" and enter a string 'COM2:9600,N,8,1' (it means using the Win-GRAF PAC's COM2 to communication with the Modbus Master) and then click  to complete the settings.




Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	10 / 12

4. Double-click the left side of the “SLV” and then enter “1” (the value set in the [Section 1.1](#) - Step 3), then click  to finish the setting.



Now, you have completed the setting of the “MBSLAVERTU” function block, and then re-compile the program and download it to the Win-GRAF PAC.


**Note:** Users can enable multiple Modbus RTU Slave ports for each PAC (recommend not over 16 Ports), the way is to add multiple “MBSLAVERTU” function blocks and set the different “Port” value.




Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	11 / 12

### 1.2.2. Add the “MBSLAVERTUEX” function block

When using several “Server - ...” settings (recommend to set one) in the “IO Drivers” window, the user needs to use the “MBSLAVERTUEX” function block.



1. Follow steps 1 to 4 above to add the “MBSLAVERTUEX” function block. If you want to change the usage for existing function block, mouse double-click the “MBSLAVERTU” and change it to the “MBSLAVERTUEX”, and then click the “OK” button.




Classification	Win-GRAF English FAQ-008						
Author	Janice Hong	Version	1.0.0	Date	Dec. 2015	Page	12 / 12

2. The “MBSLAVERTUEX” has a “SrvID” setting. Double click the left side of the “SrvID” and enter a needed “Server ID” (using a string format, e.g., ‘Svr1’).

**Note:**

Using the “MBSLAVERTU” function block means the first Modbus Slave setting will be enabled.  
 Using the “MBSLAVERTUEX” function block means to enable the Modbus Slave setting depends on the “Server ID”.



Now, you have finished the settings for the “MBSLAVERTUEX” function block, and then re-compile the program and download it to the Win-GRAF PAC.