

Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	1 / 25

How to use the XV Board within the WP-5238-CE7 PAC?


The XV board belongs to the Modbus Slave I/O board. Before using the I/O board, users must plug it into the WP-5238-CE7, and then enable the WP-5238-CE7 as a Modbus Master. Visit the XV board Selection Guide for more details: www.icpdas.com/root/product/solutions/hmi_touch_monitor/touchpad/xv-board_selection.html

The user can find all the following Win-GRAF demo projects on the CD-ROM (\Napdos\Win-GRAF\demo-project\) or download them on <ftp://ftp.icpdas.com.tw/pub/cd/win-graf-pac-cd/napdos/win-graf/demo-project/>.

Demo	File Name	Description
XV107, XV107A	demo_XV107.zip	Read 8 DI, Write 8 DO
XV110	demo_XV110.zip	Read 16 DI
XV111, XV111A	demo_XV111.zip	Read 16 DO, Read 1 DO
XV116	demo_XV116.zip	Read 5 DI, Write 6 DO
XV308_1 XV308_2 XV308_3	demo_XV308_1.zip demo_XV308_2.zip demo_XV308_3.zip	1. Read 8 AI, Read 8 DI 2. Read 8 AI, Write 8 DO 3. Read 8 AI, Write 4 DO, Read 4 DI
XV310	demo_XV310.zip	Read 4 AI, Write 4 DO, Read 4 DI, Write 4 AO

1.1. The Common Setting:


1. Mouse click the “Open Fieldbus Configuration” tool button to open the “I/O Drivers” window.



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	2 / 25

2. Double click on "RTU: COM:115200,N,8,1" to open the "MODBUS Master Port" window as the figure above.

Note: All the demo projects listed in above table enable the WP-5238-CE7 as a Modbus RTU Master device and set the "Com. Port" as "COM0:115200,N,8,1".




Configure the AI/AO channel

If you want to use the AI/AO channel of the XV Board (e.g., XV308, XV310) in the WP-5238-CE7. First, stop the Win-GRAF driver in the PAC and then configure each AI/AO channel by using "DCON_Utility_Pro_CE_200.exe".


Using the WP-5238 as an example:

1. Click the "Win_GRAF_WP_5238" (or the small icon on the taskbar) to open the Win-GRAF driver window, and then click the "End Driver" button.




Classification	Win-GRAF English FAQ-010							
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	3 / 25	


- Click "My Device" on the desktop and then get into the path "\System_Disk\Tools\dcon_utility_pro" to run the "DCON_UTILITY_Pro_CE_200.exe".



- Click the COM Port button to set the "COM Port" as "COM0", set the "Baud Rate" as "115200" and set the "Format" as "N,8,1", and then click "OK".




- After clicking the Search (▶) button, the XV Board (e.g., XV308) will show in the window. Then, double click this item to get into the setting window.




Classification	Win-GRAF English FAQ-010							
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	4 / 25	

5. In the "Configuration" tab, set the "Data Format" as "Engineering Format" (recommended setting), set the "Fast Mode" as "Fast Mode" and uncheck the "Reverse DI State (INIT*)".



6. In the "AI/AI Alarm" tab, to configure the proper ranges and values for each AI channel, and remember to select any AI channel (e.g., "CH:00") you want to use, then click the "Set Alarm" button.



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	5 / 25

XV308:

Type Code	Range	Data Format	Minimum	Maximum
05	+/-2.5 V	Engineering	-25000	+25000
		Hexadecimal	8000h	7FFFh
06	+/-20 mA	Engineering	-20000	+20000
		Hexadecimal	8000h	7FFFh
07	+4 mA ~ +20 mA	Engineering	+4000	+20000
		Hexadecimal	0000h	FFFFh
08	+/-10 V	Engineering	-10000	+10000
		Hexadecimal	8000h	7FFFh
09	+/-5 V	Engineering	-5000	+5000
		Hexadecimal	8000h	7FFFh
0A	+/-1 V	Engineering	-10000	+10000
		Hexadecimal	8000h	7FFFh
0D	+/-20 mA	Engineering	-20000	+20000
		Hexadecimal	8000h	7FFFh
1A	0 mA ~ +20 mA	Engineering	0	+20000
		Hexadecimal	0000h	FFFFh


Note:

1. For easy to use, recommended to use the data format - "Engineering". (E.g., "+/-2.5 V" will show as "-25000 to +25000" and "+4 mA to +20 mA" will show as "+4000 to +20000")
2. When using these "Type Code" - 06, 07, 0D, 1A, please check if the position of eight hardware jumpers on the XW board are correct. See the data sheet, www.icpdas.com/root/product/solutions/datasheet/hmi_touch_monitor/XV308.pdf

Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	6 / 25

Note:

When using the XV308, you need to click the "Set Power On" and "Set Safe Value" button (do not choose any DO Status) in the "DO/Alarm" tab.



7. Finally, back to the "Configuration" tab and click the "Set Module Configuration" button (Step5) to finish the AI/AO configuration, and then close the "DCON_Utility_Pro_CE_200.exe". In addition, click the "Win_GRAF_WP_5238" on the desktop to run the Win-GRAF driver (like Step 1).

XV310 - Analog Input:

Follow the similar way like the steps above to configure the AI/AO of the XV310.

Type Code	Range	Data Format	Minimum	Maximum
05	+/-2.5 V	Engineering	-25000	+25000
		Hexadecimal	8000h	7FFFh
06	+/-20 mA	Engineering	-20000	+20000
		Hexadecimal	8000h	7FFFh
07	+4 mA ~ +20 mA	Engineering	+4000	+20000
		Hexadecimal	0000h	FFFFh
08	+/-10 V	Engineering	-10000	+10000
		Hexadecimal	8000h	7FFFh
09	+/-5 V	Engineering	-5000	+5000
		Hexadecimal	8000h	7FFFh
0A	+/-1 V	Engineering	-10000	+10000
		Hexadecimal	8000h	7FFFh
0D	+/-20 mA	Engineering	-20000	+20000
		Hexadecimal	8000h	7FFFh
1A	0 mA ~ +20 mA	Engineering	0	+20000

Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	7 / 25

		Hexadecimal	0000h	FFFFh
--	--	-------------	-------	-------

Note:

1. For easy to use, recommended to use the data format - "Engineering". (E.g., "+/-2.5 V" will show as "-25000 to +25000" and "+4 mA to +20 mA" will show as "+4000 to +20000")
2. When using these "Type Code" - 0, 1, 06, 07, 0D, 1A, please check if the position of eight hardware jumpers on the XW board are correct. See the data sheet:

www.icpdas.com/root/product/solutions/datasheet/hmi_touch_monitor/XV310.pdf

XV310 - Analog Output:

Type Code	Range	Data Format	Minimum	Maximum
0	0 mA ~ +20 mA	Engineering	0	+20000
		Hexadecimal	0000h	FFFFh
1	+4 mA ~+20 mA	Engineering	+4000	+20000
		Hexadecimal	0000h	FFFFh
2	0V ~ +10 V	Engineering	0	+10000
		Hexadecimal	0000h	FFFFh
3	+/-10 V	Engineering	-10000	+10000
		Hexadecimal	8000h	7FFFh
4	0 V ~ +5 V	Engineering	0	+5000
		Hexadecimal	0000h	FFFFh
5	+/-5 V	Engineering	-5000	+5000
		Hexadecimal	8000h	7FFFh

Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	8 / 25


1.1.1. Connecting the XV107/ XV107A (8 DI, 8 DO)

The XV107/XV107A is an 8-channel digital input and 8-channel digital output board. This section provides a Win-GRAF demo project - "demo_XV107.zip". First, go to [Section 1.1](#) for the information of the XV Board before using it.

Demo description:


This demo added two data blocks. One is used to read 8 DI data and the other is used to write 8 DO data.

1. Mouse double click the 1st data block (i.e., <2> Read Input Bits) to open the setting window.





Note: (See the figure above)

The "Offset" value starts at "0" and the Modbus address of variable is equal to the "Offset" value plus 1 (Base address). Moreover, if you set the "Operation" as "Error report", the "Offset" value for the mapping variable (Date Type: DINT) must set to "0".



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	9 / 25

2. Mouse double click the 2nd data block (i.e., <15> Write Coil Bits) to open the setting window.




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	10 / 25

1.1.2. Connecting the XV110 (16 DI)

The XV110 is a 16-channel digital input board. This section provides a Win-GRAF demo project - "demo_XV110.zip". First, go to [Section 1.1](#) for the information of the XV Board before using it.


Demo description: This demo added one data block that used to write 16 DI data.

1. Mouse double click "<2> Read Input Bits" to open the setting window.



Note: (See the figure above)

The "Offset" value starts at "0" and the Modbus address of variable is equal to the "Offset" value plus 1 (Base address). Moreover, if you set the "Operation" as "Error report", the "Offset" value for the mapping variable (Date Type: DINT) must set to "0".



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	11 / 25

1.1.3. Connecting the XV111, XV111A (16 DO)

The XV111/ XV111A is a 16-channel digital output board. This section provides a Win-GRAF demo project - "demo_XV111.zip". First, go to [Section 1.1](#) for the information of the XV Board before using it.

Demo description: This demo added two data blocks. One is used to write 16 DO data and the other is used to read the DO status.

1. Mouse double click the 1st data block (i.e., <15> Write Coil Bits) to open the setting window.

Note: The "Offset" value is starting from "0" and the Modbus address of a variable is equal to this value plus 1 (Base address = 1).

Symbol	Operation	Offset	Mask	Storage	Name	Type
XV111_DO_00	Data exchange	0	FFFF	Default	XV111_DO_00	BOOL
XV111_DO_01	Data exchange	1			XV111_DO_01	BOOL
XV111_DO_02	Data exchange	2			XV111_DO_02	BOOL
XV111_DO_03	Data exchange	3			XV111_DO_03	BOOL
XV111_DO_04	Data exchange	4			XV111_DO_04	BOOL
XV111_DO_05	Data exchange	5			XV111_DO_05	BOOL
XV111_DO_06	Data exchange	6			XV111_DO_06	BOOL
XV111_DO_07	Data exchange	7			XV111_DO_07	BOOL
XV111_DO_08	Data exchange	8	FFFF	Default	XV111_DO_08	BOOL
XV111_DO_09	Data exchange	9	FFFF	Default	XV111_DO_09	BOOL
XV111_DO_10	Data exchange	10	FFFF	Default	XV111_DO_10	BOOL
XV111_DO_11	Data exchange	11	FFFF	Default	XV111_DO_11	BOOL
XV111_DO_12	Data exchange	12	FFFF	Default	XV111_DO_12	BOOL
XV111_DO_13	Data exchange	13	FFFF	Default	XV111_DO_13	BOOL
XV111_DO_14	Data exchange	14	FFFF	Default	XV111_DO_14	BOOL
XV111_DO_15	Data exchange	15	FFFF	Default	XV111_DO_15	BOOL
					XV111_status	DINT

MODBUS Master Request

Request:

Description: []

Slave/Unit: 1

MODBUS Request:

- <5> Write single coil bit
- <6> Write single holding register
- <15> Write Coil Bits
- <16> Write Holding Registers

Data block:

Base address: 1

Nb items: 16

Activation:

- Periodic: 0 ms
- On call (on error)
- On change

Misc.:

Timeout: 100 ms

Nb trials: 1

The Net-ID (fixed to "1") of the Slave device (i.e., XV board).

Write DO data.


Start from addr. 1 and write 16 data.

Write only when data changed.


An exception occurs if no respond for 100 ms.

Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	12 / 25

2. Mouse double click the 2nd data block (i.e., <1> Read Coil Bits) to open the setting window.



Note: The “Offset” value starts at “0” and the Modbus address of variable is equal to the “Offset” value plus 1 (Base address).



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	13 / 25


1.1.4. Connecting the XV116 (5 DI, 6 Relay)

The XV116 is a 5-channel digital input and 6-channel relay output board. This section provides a Win-GRAF demo project - "demo_XV116.zip". First, go to [Section 1.1](#) for the information of the XV Board before using it.

Demo description:


This demo added two data blocks. One is used to read 5 DI data and the other is used to write 6 DO data.

1. Mouse double click the 1st data block (i.e., <2> Read Input Bits) to open the setting window.





Note: (See the figure above)

The "Offset" value starts at "0" and the Modbus address of variable is equal to the "Offset" value plus 1 (Base address). Moreover, if you set the "Operation" as "Error report", the "Offset" value for the mapping variable (Date Type: DINT) must set to "0".



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	14 / 25

2. Mouse double click the 2nd data block (i.e., <15> Write Coil Bits) to open the setting window.



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	15 / 25


1.1.5. Connecting the XV308 (8 AI, 8 DIO)

The XV308 is a 8-channel analog input and 8-channel digital input/output board. This section provides three Win-GRAF demo projects - "demo_XV308_1.zip", "demo_XV308_2.zip" and "demo_XV308_3.zip". First, go to [Section 1.1](#) to view the XV Board instructions and then configure each AI channel by using "DCON_Utility_Pro_CE_200.exe".

Demo description: (demo_XV308_1)


This demo added two data blocks, one is used to read 8 AI data and the other is used to read 8 DI data.

1. Mouse double click the 1st data block (i.e., <4> Read Input Registers) to open the setting window.




Note: (See the figure above)

The "Offset" value starts at "0" and the Modbus address of variable is equal to the "Offset" value plus 1 (Base address). Moreover, if you set the "Operation" as "Error report", the "Offset" value for the mapping variable (Date Type: DINT) must set to "0".




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	16 / 25

2. Mouse double click the 2nd data block (i.e., <2> Read Input Bits) to open the setting window.



Notw: When using the XV308 to read DI data, the address must start from "33".




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	17 / 25


Demo description: (demo_XV308_2)

This demo added two data blocks, one is used to read 8 AI data and the other is used to write 8 DO data.

1. Mouse double click the 1st data block (i.e., <4> Read Input Registers) to open the setting window.





Note: The “Offset” value starts at “0” and the Modbus address of variable is equal to the “Offset” value plus 1 (Base address). Moreover, if you set the “Operation” as "Error report", the “Offset” value for the mapping variable (Data Type: DINT) must set to “0”.



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	18 / 25

2. Mouse double click the 2nd data block (i.e., <15> Write Coil Bits) to open the setting window.




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	19 / 25


Demo description: (demo_XV308_3)

This demo added three data blocks, the 1st one is used to read 8 AI data, the 2nd one is used to write 4 DO data and the 3rd one is used to read only 4 DI data.

1. Mouse double click the 1st data block (i.e., <4> Read Input Registers) to open the setting window.





Note: The “Offset” value starts at “0” and the Modbus address of variable is equal to the “Offset” value plus 1 (Base address).




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	20 / 25


2. As the figure below, mouse double click the 2nd data block (i.e., <15> Write Coil Bits) to view the setting window.



3. As the figure below, mouse double click the 3rd data block (i.e., <2> Read Input Bits) to view the setting window.



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	21 / 25



Note:
When using the XV308 to read DI data, the address must start from "33".

1.1.6. Connecting the XV310 (4 AI, 2 AO, 4 DI, 4 DO)


The XV310 is a 4-ch analog input, 2-ch analog output, 4-ch digital input and 4-ch digital output board. This section provides a Win-GRAF demo projects - "demo_XV310.zip".

First, go to [Section 1.1](#) to view the XV Board instructions and then configure each AI channel by using "DCON_Utility_Pro_CE_200.exe".

Demo Description


This demo added four data blocks. The 1st one is used to read 4 AI data, the 2nd is used to write 4 DO data, the 3rd is used to read 4 DI data and the 4th is used to write 2 AO data.

1. Mouse double click the 1st data block (i.e., <4> Read Input Registers) to open the setting window.




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	22 / 25


Note: The “Offset” value starts at “0” and the Modbus address of variable is equal to the “Offset” value plus 1 (Base address). Moreover, if you set the “Operation” as "Error report", the “Offset” value for the mapping variable (Date Type: DINT) must be set to “0”.




2. Mouse double click the 2nd data block (i.e., <15> Write Coil Bits) to view the setting window.




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	23 / 25



3. Mouse double click the 3rd data block (i.e., <2> Read Input Bits) to view the setting window.




Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	24 / 25




Note: When using the XV310 to read DI data, the base address must be set to "33".

4. Mouse double click the 4th data block (i.e., <16> Write Holding Registers)



Classification	Win-GRAF English FAQ-010						
Author	Janice Hong	Version	1.0.0	Date	Jan. 2016	Page	25 / 25



Note: When using the XV310 to write AO data, the base address must be set to "33".

The Net-ID (fixed to "1") of the Slave device (i.e., XV board).

Write AO data.

Start from addr. 33 and write two data.

Write only when data changed.

An exception occurs if no respond for 100 ms.