

EXFO Communication Driver

Driver for Serial Communication with
WA-5900 (Fiber Bragg Grating Monitor)

Contents

INTRODUCTION2

GENERAL INFORMATION.....3

 DEVICE CHARACTERISTICS3

 LINK CHARACTERISTICS.....3

 DRIVER CHARACTERISTICS3

 CONFORMANCE TESTING4

INSTALLING THE DRIVER5

CONFIGURING THE DRIVER6

 SETTING THE COMMUNICATION PARAMETERS6

 CONFIGURING THE DRIVER WORKSHEETS8

EXECUTING THE DRIVER 12

TROUBLESHOOTING 13

SAMPLE APPLICATION 15

REVISION HISTORY..... 16

Introduction

The EXFO driver enables communication between the Studio system and devices using the proprietary protocol communicating over Serial, according to the specifications discussed in this document.

This document was designed to help you install, configure and execute the EXFO driver to enable communication with these devices. The information in this document is organized as follows:

- **Introduction:** Provides an overview of the EXFO driver documentation.
- **General Information:** Provides information needed to identify all the required components (hardware and software) used to implement communication between Studio and the EXFO driver.
- **Installing the Driver:** Explains how to install the EXFO driver.
- **Configuring the Driver:** Explains how to configure the EXFO driver.
- **Executing the Driver:** Explains how to execute the driver to verify that you installed and configured the driver correctly.
- **Troubleshooting:** Lists the most common error codes for this protocol and explains how to fix these errors.
- **Sample Application:** Explains how to use a sample application to test the EXFO driver configuration.
- **Revision History:** Provides a log of all modifications made to the driver and the documentation.



Notes:

- This document assumes that you have read the “Development Environment” chapter in the Studio *Technical Reference Manual*.
- This document also assumes that you are familiar with the Windows NT/2000/XP environment. If you are unfamiliar with Windows NT/2000/XP, we suggest using the **Help** feature (available from the Windows desktop **Start** menu) as you work through this guide.

General Information

This chapter explains how to identify all the hardware and software components used to implement communication between the Studio EXFO driver and the WA-5900 device.

The information is organized into the following sections:

- Device Characteristics
- Link Characteristics
- Driver Characteristics

Device Characteristics

To establish communication, you must use devices with the following specifications:

Manufacturer: EXFO Electro-Optical Engineering Inc.

Compatible Equipment:

- WA-5900 (Fiber Bragg Grating Monitor)

For a list of the devices used for conformance testing, see “Conformance Testing” on page 4.

Link Characteristics

To establish communication, you must use links with the following specifications:

- **Device Communication Port:** RS-232
- **Physical Protocol:** RS-232
- **Logic Protocol:** Proprietary
- **Specific PC Board:** None

Driver Characteristics

The EXFO driver is composed of the following files:

- **EXFO.INI:** Internal driver file. *You must not modify this file.*
- **EXFO.MSG:** Internal driver file containing error messages for each error code. *You must not modify this file.*
- **EXFO.PDF:** Document providing detailed information about the EXFO driver
- **EXFO.DLL:** Compiled driver

Notes:

- All of the preceding files are installed in the /DRV subdirectory of the Studio installation directory.
- You must use Adobe Acrobat® Reader™ (provided on the Studio installation CD-ROM) to view the EXFO.PDF document.

You can use the EXFO driver on the following operating systems:

- Windows NT/2K/XP

For a list of the operating systems used for conformance testing, see “Conformance Testing” on page 4.

Conformance Testing

The following hardware/software was used for conformance testing:

▪ **Driver Configuration:**

- **COM Port:** COM1
- **Baud Rate:** 115200
- **Data Bits:** 8
- **Stop Bits:** 1
- **Parity:** None


Driver Version	Studio Version	Operating System	Equipment
1.03	6.1	Windows XP	WA-5900

Installing the Driver

When you install Studio version 5.1 or higher, all of the communication drivers are installed automatically. You must select the driver that is appropriate for the application you are using.

Perform the following steps to select the driver from within the application:

1. Open Studio from the **Start** menu.
2. From the Studio main menu bar, select **File** → **Open Project** to open your application.
3. Select **Insert** → **Driver** from the main menu bar to open the *Communication Drivers* dialog.
4. Select the **EXFO** driver from the *Available Drivers* list (as shown in the following figure), and then click the **Select** button.



Communication Drivers Dialog Box

5. When the **EXFO** driver displays in the **Selected Drivers** list, click the **OK** button to close the dialog.

Attention:
For safety reasons, you must use special precautions when installing the physical hardware. Consult the hardware manufacturer’s documentation for specific instructions in this area.

Configuring the Driver

After opening Studio and selecting the EXFO driver, you must configure the driver. Configuring the EXFO driver is done in two parts:

- Specifying communication parameters
- Defining tags and controls in the *STANDARD DRIVER SHEETS* (or Communication tables)


Worksheets are divided into two sections, a *Header* and a *Body*. The fields contained in these two sections are standard for all communications drivers — except the **Station**, **Header** and **Address** fields, which are driver-specific. This document explains how to configure the **Station**, **Header** and **Address** fields only.

Note:
For a detailed description of the Studio *STANDARD DRIVER SHEETS*, and information about configuring the standard fields, review the product's *Technical Reference Manual*.

Setting the Communication Parameters


Use the following steps to configure the communication parameters, which are valid for all driver worksheets configured in the system:

1. From the Studio development environment, select the *Comm* tab located below the *Workspace*.
2. Click on the *Drivers* folder in the *Workspace* to expand the folder.
3. Right-click on the EXFO subfolder. When the pop-up menu displays (as shown in the following figure), select the **Settings** option.



Select Settings from the Pop-Up Menu

The EXFO: *Communication Parameters* dialog displays (as follows).



Communication Parameters Dialog

Note:

The device must be configured with *exactly the same* parameters that you configured in the *EXFO Communication Parameters* dialog.

4. Click the **Advanced** button on the *Communication Parameters* dialog to open the *Advanced Settings* dialog and configure the settings that are necessary.

Notes:

- Do not change any of the other *Advanced* parameters at this time. You can consult the *Studio Technical Reference Manual* for information about configuring these parameters for future reference.
- Generally, you must change the *Advanced* parameter settings if you are using a DCE (Data Communication Equipment) converter (232/485 for example), modem, and so forth between the PC, driver, and the host. You must be familiar with the DCE specifications before adjusting these configuration parameters.


Configuring the Driver Worksheets

This section explains how to configure the *STANDARD DRIVER SHEETS* (or communication tables) to associate application tags with the device addresses. You can configure multiple Driver Worksheets — each of which is divided into a *Header* section and *Body* section.

Configuring the *STANDARD DRIVER SHEET*

Use the following steps to create a new *STANDARD DRIVER SHEET*:

1. From the Studio development environment, select the *Comm* tab, located below the *Workspace* pane.
2. In the *Workspace* pane, expand the *Drivers* folder and right-click the *EXFO* subfolder.
3. When the pop-up menu displays (as shown in the following figure), select the **Insert** option.



Inserting a New Worksheet

 **Note:**

To optimize communication and ensure better system performance, you must tie the tags in different driver worksheets to the events that trigger communication between each tag group and the period in which each tag group must be read or written. Also, we recommend configuring the communication addresses in sequential blocks to improve performance.

The *STANDARD DRIVER SHEET* displays (similar to the following figure).

Tag Name	Address	Div	Add
1	Tag[0]	0	
2	Tag[1]	1	
3	Tag[2]	2	
4			
5			

STANDARD DRIVER SHEET

In general, all parameters on the Driver Worksheet (except the **Station**, **Header** and **Address** fields) are standard for all communication drivers, but they will not be discussed in this document. For detailed information about configuring the standard parameters, consult the *Studio Technical Reference Manual*.

4. Use the following information to complete the **Station**, **Header** and **Address** fields on this worksheet.

- **Station** field: Not used for this driver.
- **Header** field: Use the information in the following table to define the type of commands that will be read from or written to the device.

These commands must comply with the following syntax:

<Command> (For example: ID)

After you edit the **Header** field, Studio checks the syntax to determine if it is valid. If the syntax is incorrect, Studio automatically inserts the default value in the **Header** field.

Also, you can type a tag string in brackets {**Tag**} into the **Header** field, but you must be certain that the tag's value is correct and that you are using the correct syntax, or you will get an **invalid Header** error.

- **Address** field: Use this field to associate each tag to its respective device address.

Type the tag from your application database into the **Tag Name** column. This tag will receive values from or send values to an address on the device.

The following table lists all of the Commands and address that are valid for the EXFO driver.

Commands	Address	Comments
ID	0	Model
	1	Serial number
	2	Software version
SPC	0	Spectrum output center. Range is 51 to 8141 (total range is 8192 data points)
SPL	0	Spectra output length
PFM	0	The method used for locating channels If x = 0, then the RTH value is used as a fixed threshold relative to the highest point in the spectrum. If x = 1, then a peak is defined as a channel if the peak is greater than RTH above the local noise floor.
RTH	0	The threshold level for channel definition
WTH	0	The threshold level for wavelength calculation
A	0	The number of spectra to be averaged
NOR	0	Initiates a calibration of the source (Write only)
BON	0	Turns broadcast mode on (Write only)
BOFF	0	Turns broadcast mode off (Write only)
WPO	0...255	Turns on wavelength/reflected power/OSNR measurement for continuous output / update (Read Only)
WPOBOFF	0	Turns off continuous wavelength/reflected power/OSNR measurement output broadcast (Write Only)
SW	0	The status word (Read Only)
SPO	0	The spectral output for one measurement (Read Only)
SPOBOFF	0	Turns off the continuous spectral output broadcast (Write Only)
ASN	0	Auto-calibration off or on (0 or 1 respectively)
NT	0	The interval between auto-calibrations in hours
S	0...255	The window associated with sensor
W	0...255	The range of window[j]
SENABLE	0	Enables peak search in each defined window, and polynomial conversion of each peak wavelength to an output value. Enter *1 to enable, and *0 to disable.
SENSOR	0...255	The defined sensors for their output values (Read Only)
DATE	0	The date (Write only)
TIME	0	The time (Write only)
EQX (Read only)	0	Equation that calculates pressure, temperature and delta pressure. This is a specific header for a specific client.
INIT (Write only)	1	P0 - Parameters for equations. This is a specific header for a specific client.
	2	TR - Parameters for equations. This is a specific header for a specific client.
	3	A11 - Parameters for equations. This is a specific header for a specific client.
	4	A12 - Parameters for equations. This is a specific header for a specific client.
	5	A21 - Parameters for equations. This is a specific header for a specific client.
	6	A22 - Parameters for equations. This is a specific header for a specific client.
	7	L1rt - Parameters for equations. This is a specific header for a specific client.

Commands	Address	Comments
	8	L2rt - Parameters for equations. This is a specific header for a specific client.
	9	L1rp - Parameters for equations. This is a specific header for a specific client.
	10	L2rp - Parameters for equations. This is a specific header for a specific client.
	11	Grad - Parameters for equations. This is a specific header for a specific client.
CFG (Write only)	0	Configuration header. This is a specific header for a specific client.


Executing the Driver

After adding the EXFO driver to a project, Studio sets the project to execute the driver automatically when you start the run-time environment.

To verify that the driver run-time task is enabled and will start correctly, perform the following steps:

1. Select **Project** → **Status** from the main menu bar.

The *Project Status* dialog box displays, as follows.



Project Status Dialog Box

2. Verify that the *Driver Runtime* task is set to **Automatic**.
 - If the setting is correct, click **OK** to close the dialog box.
 - If the **Driver Runtime** task is set to **Manual**, select the **Driver Runtime** line. When the **Startup** button becomes active, click the button to toggle the *Startup* mode to **Automatic**.
3. Click **OK** to close the *Project Status* dialog.
4. Start the application to run the driver.

Troubleshooting

If the EXFO driver fails to communicate with the device, the tag you configured for the **Read Status** or **Write Status** fields will receive an error code. Use this error code and the following table to identify the type of failure.

Error Code	Description	Possible Causes	Procedure to Solve
0	OK	Communication without problems	None required
1	ERROR PROTOCOL	The driver receives an invalid message.	Verify that the command is valid to read or write.
2	ERROR INVALID COMMAND	The command specified in the Header field is invalid.	Verify that the command specified in the Header field is valid.
3	ERROR CONNECTION	The equipment is not properly connected.	Check connections.
4	ERROR CONFIGURATION	If using (EQX), the Grad number informed might be different from the Grad number returned from the equipment.	If (EQX), try to set different values for RTH and WTH to avoid noises.
-15	Timeout Start Message	<ul style="list-style-type: none"> ▪ Disconnected cables ▪ PLC is turned off, in stop mode, or in error mode ▪ Wrong station number ▪ Wrong RTS/CTS control settings 	<ul style="list-style-type: none"> ▪ Check cable wiring. ▪ Check the PLC state – it must be RUN. ▪ Check the station number. ▪ Check the configuration. See Studio <i>Technical Reference Manual</i> for information about valid RTS/CTS configurations.
-17	Timeout between rx char	<ul style="list-style-type: none"> ▪ PLC in stop mode or in error mode ▪ Wrong station number ▪ Wrong parity ▪ Wrong RTS/CTS configuration settings 	<ul style="list-style-type: none"> ▪ Check cable wiring. ▪ Check the PLC state – it must be RUN. ▪ Check the station number. ▪ Check the configuration. See Studio <i>Technical Reference Manual</i> for information about valid RTS/CTS configurations.

⇒ **Tip:**

You can verify communication status with the Studio development environment *Output* window (*LogWin* module). To establish an event log for **Field Read Commands**, **Field Write Commands** and **Serial Communication**, right-click in the *Output* window. When the pop-up menu displays, select the option to set the log events. If you are testing a Windows CE target, you can use the Remote LogWin of Studio (**Tools** → **Remote Logwin**) to get the log events from the target unit remotely.

If you are unable to establish communication with the PLC, try to establish communication between the PLC Programming Tool and the PLC. Quite frequently, communication is not possible because you have a hardware or cable problem, or a PLC configuration error. After successfully establishing communication between the device's Programming Tool and the PLC, you can retest the supervisory driver.

To test communication with Studio, we recommend using the sample application provided rather than your new application.

If you must contact us for technical support, please have the following information available:

- **Operating System** (type and version): To find this information, select **Tools** → **System Information**.
- **Studio version**: To find this information, select **Help** → **About**.
- **Driver Version**: To find this information, read the full description of the driver on the **Communication Drivers** Dialog Box.

- **Communication Log:** Displays in the Studio *Output* window (or *LogWin* window) when the driver is running. Be sure to enable the **Field Read Commands**, **Field Write Commands** and **Serial Communication** for the LogWin window.
- **Device Model and Boards:** Consult the hardware manufacturer's documentation for this information.

Sample Application

You will find a sample application for drivers in the `/COMMUNICATION EXAMPLES/EXFO` directory. We strongly recommend that you check for a sample application for this driver and use it to test the driver before configuring your own, customized application, for the following reasons:

- To better understand the information provided in each section of this document.
- To verify that your configuration is working satisfactorily.
- To certify that the hardware used in the test (device, adapter, cable and PC) is working satisfactorily before you start configuring your own, customized applications.



Note:

This application sample is not available for all drivers.

Use the following procedure to perform the test:

1. Configure the device's communication parameters using the manufacturer's documentation.
2. Open and execute the sample application.



Tip:

You can use the sample application screen as the maintenance screen for your custom applications.

Revision History

Doc. Revision	Driver Version	Author	Date	Description of changes
A	1.00	Eric Vigiani	Dec/06/2004	Initial version
B	1.01	Fabio Carvalho	Apr/29/2005	New commands implemented for client – INIT, CFG, EQX
C	1.02	Leandro Coeli	Mar/15/2006	Changes in WPO
D	1.03	Leandro Coeli	Mar/15/2006	Cleaned the buffers