

分類/Classification	<input type="checkbox"/> tDS	<input type="checkbox"/> tGW	<input type="checkbox"/> PETL/tET/tPET	<input type="checkbox"/> DS/PDS/PPDS	<input type="checkbox"/> tM-752N
	<input type="checkbox"/> I/O Card	<input type="checkbox"/> VXC Card	<input checked="" type="checkbox"/> VxComm		<input type="checkbox"/> Other
作者/Author	Gary Lin	日期/Date	2002-02-25	編號/NO.	FAQ-002

Q: Does VxComm Driver (PC) support auto-reconnection after fixing a network break?

A: Yes, the VxComm Driver (PC) supports the auto-reconnection mechanism in version 2.00 and above. The VxComm Utility allows the user to set the Keep-Alive Time (ms) and Connection-Broken Time (ms) in the server options.

For more details, refer to the "**Adding a 7188E/8000E/PDS-700/DS-700 server and configuring the VxComm Driver**" section of the VxComm Driver/Utility User Manual.