

分類/Classification	<input type="checkbox"/> tDS	<input type="checkbox"/> tGW	<input type="checkbox"/> PETL/tET/tPET	<input type="checkbox"/> DS/PDS/PPDS	<input type="checkbox"/> tM-752N
	<input type="checkbox"/> I/O Card	<input type="checkbox"/> VXC Card	<input checked="" type="checkbox"/> VxComm	<input type="checkbox"/> Other	
作者/Author	Gary Lin	日期/Date	2003-12-09	編號/NO.	FAQ-004

Q: How do I change the virtual COM port mapping on the fly without using the VxComm Utility?

A: The VxComm Driver for NT and 2K/XP uses the VxComCfg.DLL to export functions and import configuration from a given file.

An article – **VxComCfg_vx.x.txt** to describe the VxComCfg.DLL, has been installed into the "**C:\ICPDAS\VxComm W7\VxComCfg**" directory after the driver setup. VB examples and other materials can be found besides in the same location. Please refer to them for further information.