

MSM Series Switch Quick Start

Industrial Managed Ethernet Switch

Applied to models MSM-6226

Version 1.0, April. 2011

1

What's on your package?

1. One MSM Series Switch
2. One companion CD
3. One Quick Start Guide (this document)
4. One RS-232 download cable
5. One Power cord
6. Mounting Accessory (for 19" Rack Shelf)

2

Preparing for start-up

1. AC Line 100-240V 50-60Hz power supply.
2. Make sure your PC has workable network settings.
3. Copy 7188xw.exe to your PC.

You can find it from the companion CD (\Napdos\7188XW\) ,or
download the latest version from ICP DAS website.

<http://www.icpdas.com/products/Switch/industrial/software.htm>

3

Connecting the Power and Host PC



RS-232 DB-9 Connector



**AC Line 100-240V
50/60 Hz**



RS-232



Terminal or Terminal Emulator

**MSM-6226 L2 Managed Switch
Default IP Setting:
IP address = 192.168.1.1
Subnet Mask = 255.255.255.0
Default Gateway = 192.168.1.254**

**RS-232 cable with female
DB-9 connector at both
ends**

4

Quick configuration

1. Turn on MSM Series Switch power.
2. Execute 7188xw.exe utility and press ENTER

Baud rate	57600
Stop bits	1
Data bits	8
Parity	N

3. Setting the IP, Mask, Gateway to fit your network.
You can type '?' or 'help' to list all console commands
4. When you finish the network setting, you have to reboot MSM Series Switch to enable the setting values.
5. Execute web browser application, connect to the Switch Web Management with the new setting IP.



6. If connection succeeds, a login form will display.
Default User Name : admin
Default password : admin
7. When authentication succeeds, you can see a welcome information display.

For more detail configuration of Web Management, please refer to the MSM Web Management Manual in the CD,

CD:\Napdos\MSM-6226\manual\

or download from ICP DAS website.

<http://www.icpdas.com/products/Switch/industrial/software.htm>

Additional Information

◆ MSM Series Switch Manual :

CD:\Napdos\MSM-6226>manual\

<http://www.icpdas.com/products/Switch/industrial/software.htm#manu>

◆ MSM Series Switch firmware :

CD:\Napdos\MSM-6226\firmware\

<http://www.icpdas.com/products/Switch/industrial/software.htm>

◆ The ICP DAS Web Site

<http://www.icpdas.com>

- Technical support
- Supplies and ordering information
- Information to enhance the product
- FAQ & Application story

◆ Contact Us

Service@icpdas.com

<http://www.icpdas.com/sevices/support.htm>

