

分類/Classification	<input type="checkbox"/> tDS	<input type="checkbox"/> tGW	<input type="checkbox"/> PETL/tET/tPET	<input type="checkbox"/> DS/PDS/PPDS	<input type="checkbox"/> tM-752N
	<input type="checkbox"/> I/O Card	<input type="checkbox"/> VXC Card	<input checked="" type="checkbox"/> VxComm		<input type="checkbox"/> Other
作者/Author	Gary Lin	日期/Date	2002-03-12	編號/NO.	FAQ-003

**Q: Will the VxComm Driver allow the SetCommState() API to dynamically change the baud rate, data bits, parity and stop bits?**

A: Yes. In the Win32 environment, users should call the CreateFile( ) API to open the COM port(s) and then use the SetCommState( ) API to configure it.

Third-party tools may provide an OpenCom( ) function for the easy opening of COM ports. In actuality, they must use the CreateFile( ) and SetCommState( ) APIs to implement these kinds of functions.