How to find the system information

Applies to:		
Platform	**OS version**	**XPAC utility version**
XPAC series	All versions (WinCE6)	All versions

To find the system information, perform the following steps:

Step 1: Start the XPAC Utility on the desktop, and then select the "Device Information" tab.