

Classification	System and Application FAQ on WinCE PAC				No.	1-005-03	
Author	Tunglu-Yu	Version	1.0.0	Date	2010/2/12	Page	1/3

How to calibrate a Penmount USB touch panel


Applies to:

<i>Platform</i>	<i>OS version</i>	<i>WinPAC/ViewPAC utility version</i>
<i>WP-8x3x</i>	<i>All versions</i>	<i>All versions</i>
<i>WP-8x4x</i>	<i>All versions</i>	<i>All versions</i>
<i>VP-25W1</i>	<i>N/A</i>	<i>N/A</i>
<i>VP-23W1</i>	<i>N/A</i>	<i>N/A</i>

N/A: Not applicable to this platform and OS.

Tips & Warnings

 *To use a touch panel and a keyboard at the same time on WP-8x4x, you need a USB hub to expand the single USB port into several.*



Classification	System and Application FAQ on WinCE PAC				No.	1-005-03	
Author	Tunglu-Yu	Version	1.0.0	Date	2010/2/12	Page	2/3

To calibrate a Penmount USB touch panel, perform the following steps:


Step 1: Execute the calibration program.

1.1. Click Start → USB_TOUCH → PenMount → Calibration.




1.2. Click the “4 Points” button.

(Pressing the “9 Points” or “16 Points” button could process a more accurate calibration)



Classification	System and Application FAQ on WinCE PAC				No.	1-005-03	
Author	Tunglu-Yu	Version	1.0.0	Date	2010/2/12	Page	3/3

1.3. Touch the “” icons on the monitor to perform the calibration process.



Step 2: Save and Reboot your WinPAC.

- 2.1. Start the Win PAC utility on the desktop and click “**File**” → “**Save and Reboot**”.
- 2.2. Click the “**Yes**” button and wait for the device to reboot.

