

| | | | | | | | |
|----------------|---|---------|-------|------|------------|----------|-----|
| Classification | System and Application FAQ on WinCE PAC | | | | No. | 2-015-00 | |
| Author | Eric_Shiu | Version | 1.0.0 | Date | 2018/04/27 | Page | 1/2 |


How to change the desktop background image

Applies to:


| Platform | OS version | PAC utility version |
|----------------|--------------|---------------------|
| WinPAC series | All versions | All versions |
| ViewPAC series | All versions | All versions |

If the user do not like the desktop background image of “WinCE5.0”. Please preform the follow steps to change the desktop background image.

Note: The desktop background image needs be a pixel-based bitmap image file (*.bmp) and it is displayed as below:



Step 1: Open the **Control panel** by clicking Start >> Settings >> Control Panel, and then double click the display icon or text.



| | | | | | | | |
|----------------|---|---------|-------|------|------------|----------|-----|
| Classification | System and Application FAQ on WinCE PAC | | | | No. | 2-015-00 | |
| Author | Eric_Shiu | Version | 1.0.0 | Date | 2018/04/27 | Page | 2/2 |

Step 2: Click the Background tag and click **Browse** to choose the image file you want. After selecting the image file, clicking OK at the top right of the pop-up dialog, and then click OK on Display Properties window.

Note: The image file needs be a *.bmp file and be saved in System_disk folder.

