How to set the taskbar always on top?

| Applies to:		
Platform	*OS Version*	*PAC Utility Version*
WinPAC	*All Versions*	*All Versions*
ViewPAC	*All Versions*	*All Versions*

Depending on your preferences, you may want to set the taskbar to be always on top; it means that the taskbar is not shielded by other windows. To set the taskbar to be always on top, perform the following steps:

Step 1: Set the taskbar on top.

1.1. Click the "**Properties**".

1.2. Check the "**Always On Top**" option.

The taskbar will not be covered by any other windows**.**