Classif	fication	System and A	nnlication	FAO on XE	240		No	1-004-02				
Author WeiKai Version 1.0.1 Date 2011/6/20							Page	1/6				
Aution		vveir\di	V CI SIUI I	1.0.1	Dale	2011/0/29	raye	1/0				
How to set up an ELO USB touch panel												
Appli	Applied to: Platform OS version VPAC utility version											
	Platform		OS VE	ersion		XPAC utility version						
·	XPAC S	eries	All Ve	rsions (vvii	nCE6)	All versions						
N/A:	N/A: Not applicable to this platform and OS.											
Use a touch panel and a keyboard at the same time on XP-8x4x.												
The XP-8x4x series only has two USB ports, so if you want use a touch panel and keyboard/mouse at the same time. You will need a USB hub.												
			ICP DAS	Co., Ltd. 7	<u>Fechnical</u>	document						

	1									
Classification	System and Ap	plication F	AQ on XPAC			No.	1-004-02			
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	2/6			
To use an ELO U	To use an ELO USB touch panel, perform the following steps:									
Step 1: Location of the devices for the touch panel The ELO_USB_TOUCH_V1.14_20101101_XPAC_CE6.CAB and ELO_USB_TOUCH_V2.2_yyyymmdd_XPAC_CE6.CAB file is located at (yyyymmdd means Year /Month/ Day) 1. CD:\System_Disk\External_device_driver\ 2. <u>ftp://ftp.icpdas.com/pub/cd/xpac-atom-ce6/system_disk/external_device_driver/</u> (XP-8000-CE6) <u>ftp://ftp.icpdas.com/pub/cd/xpac-atom-ce6/system_disk/external_device_driver/</u> (XP-8000-Atom-CE6)										
Step 2: Install the ELO_USB_TOU	ne ELO_USB_T CH_V2.2_yyyyr	OUCH_∨ nmdd_XP	′1.14_yyyymm ′AC_CE6.CAE	dd_XPA 3 file.	C_CE6.CAB	or				
2.1. Double click ELO_USB_TOU	the ELO_USB CH_V2.2_yyyyr	_TOUCH_ nmdd_XP	_V1.14_yyyym PAC_CE6.CAE	mdd_XF 3 file, an	PAC_CE6.CA d then click "	NB or OK".				
ELO_USB_IOUCH_V2.2_yyyymmdd_XPAC_CE6.CAB file, and then click "OK".     Install ICPDAS USB ELO      Install CPDAS USB ELO      Install complete!!     Press 'OK' button to reboot the system, and the settings will take effect.										
ICP DAS Co., Ltd. Technical document										

Classification	System and Ap	No.	1-004-02				
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	3/6

Step 3: Execute the calibration program.

3.1. After rebooting, click Start->Programs->USB\_TOUCH->ELO-> EloVa.



ICP DAS Co., Ltd. Technical document

Classification	System and Ap	No.	1-004-02				
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	4/6

3.2. Perform the calibration process.3.2.1. Touch the "+" icons on the monitor to perform the calibration process.



Classification	System and A	pplication F	FAQ on XPAC			No.	1-004-02		
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	5/6		
Uninstall ELO USB touch driver, and perform the following steps: Step 1: Execute the Remove Program. 1.1 click the Start->Settings ->Control Panel. Programs Favorites Settings Control Panel									
Start	<u>N</u> etwork and S <u>1</u> askbar and S	itart Menu	SCOOLS						
1.2 After Open "(	Control Panel"	, double cl	ick "Remove F	rogram	s".				
Regional Settings Programs Storage Manager System									
Step 2: Uninsta	II Penmount U	I <mark>SB t</mark> ouch	driver.						
2.1 After execute	e "Remove Pro	ograms", cl	ick "ICPDAS L	JSB ELO	O" and then c	lick "Remov	e" button		
Remove Programs       OK ×         Remove Programs       Programs:         automatically removed. To remove a program, select h from the list and then select Remove.       Programs:         Remove       Remove									
2.2 Click "Yes" button, and will uninstall ELO USB touch driver.									
Remove Programs The selected program will be permanently removed. Are you sure you want to remove it? Yes No ICP DAS Co., Ltd. Technical document									
		ICP DAS	Co., Ltd. Tech	nical do	cument				

