Classification Author	System and A WeiKai	Application FAQ on XP	AC Date	2011/6/29	No.	1-004-03 1/6
					Page	1/0
low to set	t up a Pen	mount USB to	uch par	nel		
Applies to: Platform	n			VDAC /	tilitu voroic	
XPAC s		OS version All versions (Win	CE6)		tility versio /ersions	
N/A: Not app	licable to this p	platform and OS.				
	nonaland	a kaybaard at th	o oomo 4	imo on VD	Qv Av	
se a touch	panel and	a keyboard at the	e same t		-0X4X.	
		has two USB por	-		e a toucł	n panel an
eyboard/mc	ouse at the s	ame time. You wi	ll need a	USB hub.		
1	0				A	
4						
6				8 8	8 8	
9					19	
	<u> </u>	ا الق الق الم		8		
T		. 			3	
			US	SB Hub 🚡		
	h				U	
					ī	
	Contraction of the second			- 1		
		CONFERENCE IN THE SECOND				
	L					
	-					

Classification	System and A	pplication I	FAQ on XPAC			No.	1-004-03
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	2/6
To use a Penmo		•		wing ste	ps:		
Step 1: Locatio The PenMount_ means Year /Mc 1. CD:\System_I 2. <u>ftp://ftp.icpdas</u> <u>ftp://ftp.icpdas</u> CE6)	USB_TOUCH_ onth/ Day) Disk\External_ s.com/pub/cd/x	_V3.3_yyy device_dri <u>p-8000-ce</u>	ymmdd_XPAC ver\ <u>6/system_disk</u>	/externa	l_device_driv	<u>er/</u> (XP-800	0-CE6)
Step 2: Install t	he PenMount_	USB_TOL	JCH_V3.3_yyy	ymmdd_	XPAC_CE6.0	CAB file.	
2.1. Double click "OK".	the PenMoun	t_USB_TC	DUCH_V3.3_y	yyymmdo	d_XPAC_CE6	6.CAB file, a	and then click
Install ICPDAS	USB PenMount	E e	E III	OK	×		
My Device	Tomo		List				
Application Dat My Documents Program Files System_Disk	: 🗁 Windows & Control P						
Name: (Instal He	re) <u>T</u> ype:						
2.2 Double click install Install com Press 'OK'				will take et	DKX		
		ICP DAS	Co., Ltd. Tech	nical doc	ument		

Classification	System and Application FAQ on XPAC No.						1-004-03
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	3/6

Step 3: Execute the calibration program.

3.1. After rebooting, click the Start->USB_TOUCH->PenMount-> Calibration.



3.2. Click the "4 Points" button. (Click the "9 Points" or "16 Points" button to obtain a more accurate calibration for the touch panel)

Calibration Mode Select Click on the preferred mode Wait 4 seconds to 9 Points 4 Points 9	Points 16 Points
ICP D	AS Co., Ltd. Technical document

Classification System and Application FAQ on XPAC							1-004-03
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	4/6
3.3. Perform the 3.3.1. Touch the	e calibration pro	DCESS. n the moni					
4	5			3			
		ICP DAS					

Classification	System and Ap	plication F	AQ on XPAC			No.	1-004-03
Author	WeiKai	Version	1.0.1	Date	2011/6/29	Page	5/6

To Uninstall Penmount USB touch driver, perform the following steps:

Step 1: Execute the Remove Program.

1.1 click the Start->Settings ->Control Panel.

Programs	*	
🔆 Favorites	۶	
Documents	×	
🐓 Settings	۶	🚰 Control Panel
🗇 <u>R</u> un		Setwork and Dial-up Connections
2 /Start		🛃 Taskbar and Start Menu

1.2 After Open "Control Panel", double click "Remove Programs".



Step 2: Uninstall Penmount USB touch driver.

2.1 After execute "Remove Programs", click "ICPDAS USB PenMount" and then click "Remove" button

Remove Programs	ок 🗴		
Remove Programs The listed software can be programs: automatically removed. Tre remove a program, select to from the list and then select Remove. Remove	8 PenMount		

2.2 Click "Yes" button, and will uninstall Penmount USB touch driver.



