

VP-23W1/VP-25W1 User Manual

Version 1.0.4, April 2010

Service and usage information for



VP-23W1



VP-25W1

Written by Mac Cho

Edited by Anna Huang

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, not for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright @ 2009 by ICP DAS Co., Ltd. All rights are reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Contact US

If you have any problem, please feel free to contact us.
You can count on us for quick response.

Email: service@icpdas.com

Table of Contents

1. Introduction.....	7
1.1. Features	8
1.2. Specifications.....	12
1.3. Dimensions.....	14
1.4. Overview.....	16
1.5. Companion CD	18
2. Getting Started.....	19
2.1. Mounting the Hardware	19
2.2. Connecting Power and I/O Devices	23
2.3. Inserting I/O Modules.....	24
2.4. Mounting the Waterproof	27
2.5. Configuring the Boot Mode	29
2.6. Testing the ViewPAC.....	33
2.7. Using ViewPAC Utility to manage the ViewPAC	35
2.8. Using DCON Utility to Configure the I/O Modules.....	36
3. Tools and Tasks	38
3.1. DCON Utility	41
3.2. NAPOPC_CE5.....	42
3.3. SendToCOM	43
3.4. VCEP	44
3.5. ViewPAC Utility	45
3.5.1. Menu Bar	46
3.5.2. Property Tabs	51

4. Your First ViewPAC Program.....60

4.1. Preparing the Development Tools.....	60
4.2. Installing ViewPAC SDKs.....	60
4.3. Understanding the ViewPAC APIs	61
4.3.1. ViewPAC SDK Overview	62
4.3.2. ViewPAC SDK Reference	65
4.4. Your First Program in C#	67
4.4.1. Create a new project	67
4.4.2. Add project reference for an application	69
4.4.3. Design and Build an application program	70
4.4.4. Execute the application on the ViewPAC	74
4.5. Your First Program in VB.net	76
4.5.1. Create a new project	76
4.5.2. Add project reference for an application	78
4.5.3. Design and Build an application program	79
4.5.4. Execute the application on the ViewPAC	82
4.6. Your First Program in eMbedded Visual C++.....	84
4.6.1. Create a new Forms-Based project	84
4.6.2. Configure compiler options	89
4.6.3. Specify the path for project reference	90
4.6.4. Design and Build an application program	94
4.6.5. Execute the application program on ViewPAC.....	98

5. APIs and Demo References99

5.1. Demo programs with C#	100
5.1.1. C# Demo program for WinPAC Standard API.....	100
5.1.2. C# Demo program for PAC IO API.....	102
5.1.3. C# Demo program for ViewPAC Particular API.....	105
5.2. Demo Programs with eMbedded Visual C++	106

5.2.1. eVC Demo program for WinPAC Standard API	106
5.2.2. eVC Demo program for PAC IO API	108
5.2.3. eVC Demo program for ViewPAC Particular API	111
6. ViewPAC Updates	112
6.1. OS updates.....	113
6.1.1. Updating the Boot Loader and the ViewPAC OS image from files.....	115
6.1.2. Updating the ViewPAC OS image from eshell	121
6.2. SDKs Updates	126
6.2.1. WinPAC SDK updates for C# or VB.net.....	127
6.2.2. WinPAC SDK updates for eMbedded Visual C++	128
7. ViewPAC Download Center.....	129
Appendix A. I-8K and I-87K Modules	130
Appendix B. Application of RS-485 Network	131
B.1. Basic RS-485 Network	131
B.2. Daisy Chain RS-485 Network.....	132
B.3. Star Type RS-485 Network.....	133
B.4. Random RS-485 Network	135
B.5. Master/Slaves Settings.....	136
B.5.1. ViewPAC as a Master (default):.....	136
B.5.2. ViewPAC as a Slave:.....	138
Appendix C. Tips – How to	140

C.1. How to establish a new telnet and FTP account	141
C.2. How to online debug ViewPAC.....	143
C.2.1. Debug ViewPAC programs in EVC++	143
C.2.2. Debug ViewPAC programs in Visual Studio 2005/2008	153
C.3. How to recompile WinCon programs.....	161
C.3.1. Compiler old programs which ran on Wincon 8x3x and 8x4x.....	162
C.3.2. Modify .vcp file to upgrade the old WinCon project	166
C.4. How to use the printer	167
C.4.1. How to use network printer	168
C.4.2. How to use printer via USB	170
C.5. How to use services tool	171
Appendix D. Revision History	174

1. INTRODUCTION



ViewPAC combines WinPAC, graphic display and keypad in one unit. It equips a PXA270 CPU (520 MHz) running Windows CE.NET 5.0 operating system, various connectivity (USB, Ethernet, RS-232/485), 3 slots to expand I/O modules, 3.5"/5.7" TFT LCD and a rubber keypad.

Its operating system, Windows CE.NET 5.0, has many advantages, includes hard real-time capability, small core size, fast boot speed, interrupt handling at a deeper level, achievable deterministic control and low cost. Running Windows CE.NET 5.0 in the ViewPAC gives it the ability to run PC-based control software such as Visual Basic.NET, Visual C#, Embedded Visual C++, SCADA software, Soft PLC ...etc.

Compared with traditional IPC + PLC solutions, ViewPAC reduces overall system cost, space and gives you all the best features of IPC and PLC

1.1. FEATURES

This section provides a brief overview of all the major features of ViewPAC.

Software Features

✓ **Windows CE .Net 5.0 Inside**

Most of the popular features in MS software are included, such as

1. FTP Server
2. HTTP Server
3. ASP (Java script, VB script)
4. SQL Server Compact Edition 3.5
5. Compact .Net Framework 2.0

✓ **Remote Maintenance via FTP Server and VCEP Software**

The FTP server is used for uploading applications or downloading data. And VCEP is designed for managing the ViewPAC. VCEP can synchronize every movement (screen, keyboard and mouse actions) between the PC and the ViewPAC via the Ethernet. By using the FTP server and VCEP, you can update and manage the ViewPAC remotely via the Ethernet.

✓ **Built-In OPC Server (NAPOPC_CE5)**

NAPOPC_CE5 is an OPC server and SCADA software can easily integrate I/O modules through it. Furthermore, it also provides a library which users can use to develop their AP by eVC, C# or VB.Net.

NAPOPC_CE5 not only supports I/O modules in local slots, but also supports remote I/O modules with the following protocols via the RS-232/485 or Ethernet:

1. Modbus/RTU
2. Modbus/ASCII
3. Modbus/TCP
4. DCON

✓ Rich Software Solutions

On the ViewPAC, ICP DAS provides the following software solutions to fit in different applications.

1. Visual Studio .Net 2003/2005/2008 and eVC solution:

SDK as well as demo programs for C#, VB.Net and eVC are provided.

2. SoftPLC solution:

A. ISaGRAF supports IEC61131-3 languages, Ladder Diagram (LD), Structured Text (ST), Function Block Diagram (FBD), Sequential Function Chart (SFC), Instruction List (IL), and Flow Chart (FC).

B. KW-software supports IEC61131-3 languages and HMI features.

3. SCADA solution:

Indusoft provides simple “drag and drop”, “point and click” developing environment for HMI and SCADA applications.

Hardware Features

- ✓ **PXA 270 CPU (32-bit & 520 MHz)**
- ✓ **IP65 Compliant Front Panel**
- ✓ **3.5"/5.7" TFT LCD (5.7" LCD is with Touch Panel)**
- ✓ **Rubber Keypad with 24/6 Keys**

The rubber keypad has following benefits

1. Easy to dial
2. Long operation life up to 500k cycles
3. Most of function keys are customizable

- ✓ **Audio with MIC-In and Line-Out**
- ✓ **64-bit Hardware Serial Number for Software Protection**

The 64-bit hardware serial number is unique and individual. Every serial number of ViewPAC is different. Users can add a checking mechanism to their AP to prevent software from pirating.

- ✓ **3 Slots for High Profile I/O Modules**

The I/O slots support parallel bus type (high profile I-8K series) and serial bus type (high profile I-87K series) I/O modules. There are more than 60 kinds of module for AI, AO, DI, AO, counter input, frequency input, PWM output, motion control, memory, communication, etc.

- ✓ **Rich I/O Expansion Ability**

There are 7 kinds of communication interfaces (Ethernet, RS-232/485, USB ports, CAN bus, FRnet, GSM/GPRS, ZigBee) to expand I/O modules and connect external devices.

- ✓ **One Ethernet Port**
- ✓ **2 Serial Ports (RS-232, RS-485)**

✓ Dual Battery Backup SRAM (512 KB)

To maintain important data while power off, non-volatile memory is the ideal design. ViewPAC equips a 512 KB SRAM with two Li-batteries to maintain data while power off. The two Li-batteries can continually supply power to the 512 KB SRAM to retain the data for 5 years; and the dual-battery design can avoid data lost while replacing a new battery.

✓ Operating Temperature: -20 ~ +70 °C



ViewPAC is housed in a plastic-based box with a column-like ventilator that can help to cool the working environment inside the box and allow it operate between -20 ~ +70°C.

1.2. SPECIFICATIONS

This section details the specifications and supplemental characteristics of the ViewPAC.

System Software	VP-23W1	VP-25W1
OS	Windows CE .NET 5.0	
.Net Compact Framework	2.0	
Embedded Service	FTP server, Web server (supports VB script, JAVA script), Embedded SQL server	
SDK Provided	Dll for eVC, Dll for Visual Studio.Net 2005/2008	

CPU Module	VP-23W1	VP-25W1
CPU	PXA270 or compatible (32-bit and 520 MHz)	
SDRAM	128 MB	
Dual Battery Backup SRAM	512 KB (for 5 years data retention)	
Flash	96 MB (64 MB for OS image, 31 MB for built-in Flash disk, 1 MB for registry)	
EEPROM	16 KB (data retention: 40 years; 1,000,000 erase/write cycles)	
Expansion Flash Memory	microSD socket with one 1 GB microSD card (support up to 16 GB microSDHC card)	
RTC (Real Time Clock)	Provide seconds, minutes, hours, date of week/month; month and year, valid from 1980 to 2079	
64-bit Hardware Serial Number	Yes	
Dual Watchdog Timer	Yes	
Rotary Switch	Yes (0 ~ 9)	

I/O Expansion Slots	VP-23W1	VP-25W1
Slot Number	3 (for high profile I-8K and I-87K modules only)	
Hot Swap *Will be available	Yes (for high profile I-87K modules only)	

Mechanical	VP-23W1	VP-25W1
Dimension (W x D x H)	182 mm x 158 mm x 114 mm	
Ingress Protection	Front panel: IP65	

Communication Interface	VP-23W1	VP-25W1
Ethernet Port	RJ45 * 1, 10/100 Base-TX (Auto-negotiating, Auto MDI/MDIX, LED indicators)	
USB 1.1 (host)	1	
COM0	Internal communication with the high profile I-87K series modules in slots	
COM2	RS-485 (D2+, D2-; self-tuner ASIC inside); 2500 V _{DC} isolated	
COM3	RS-232 (TxD, RxD, CTS, RTS, DSR, DTR, CD, RI and GND); Non-isolated	

Main Machine Interface	VP-23W1	VP-25W1
LCD	3.5" TFT (Resolution 320 x 240)	5.7" TFT (Resolution 640 x 480)
Touch Panel	-	Yes
Rubber Keypad	24 Keys	6 Keys
Audio	Microphone-In and Earphone-Out	
LED Indicators	3 Dual-Color LEDs (PWR, RUN, LAN1, L1, L2, L3; L1 ~ L3 for user programmable)	

Environmental	VP-23W1	VP-25W1
Operating Temperature	-20 ~ +70 °C	
Storage Temperature	-30 ~ +80 °C	
Ambient Relative Humidity	10 ~ 90% RH, non-condensing	


Power	VP-23W1	VP-25W1
Input Range	+10 V ~ +30 V	
Isolation	1 kV	
Capacity	2.5 A, 5 V supply to I/O expansion slots	
Consumption	7.2 W (0.3 A @ 24 V)	

1.3. DIMENSIONS


This section provides the mounting dimensions and cut-out dimensions for the current installation of panel mounting.

All dimensions in millimeter.


VP-23W1




Front View



Side View




Rear View




Recommended
Panel Cut-Out


VP-25W1




Front View



Side View



Rear View




Recommended
Panel Cut-Out

1.4. OVERVIEW

This section provides a basic overview of what the term named in the unit.

VP-23W1



VP-25W1

LED Indicators 5.7" 640 x 480 LCM




6 Programmable Keys

microSD




I/O Expansion Slots



1.5. COMPANION CD

This section describes the content of the companion CD, which provides the resource, tool kit, software and documentation related to the ViewPAC.




2. GETTING STARTED

This chapter describes installation, basic configuration and fundamental operating principle needed to install and set up the ViewPAC.

2.1. MOUNTING THE HARDWARE

The ViewPAC can be mounted on a panel of maximum thickness 12 mm. Adequate access space can be available at the rear of the instrument panel for wiring and servicing purposes. The layout dimensions are shown below.

Panel thickness up to 12mm




Tips & Warnings




To ensure proper ventilation for your ViewPAC, leave a minimum of 50mm space between the top and bottom edges of the ViewPAC and the enclosure panels.


Step 1: Prepare the panel and cut the hole to the specified size




Step 2: Attach the ViewPAC to the cut-out hole



Step 3: Insert the panel mounting clips into the upper and lower ventilation holes



Step 4: Screw the panel mounting clips to the panel




2.2. CONNECTING POWER AND I/O DEVICES

The ViewPAC enables a power with input range of +10 V~ 30 V.


The ViewPAC equipped with a USB port that allows you connect a USB keyboard or USB mouse.

The diagram below shows the connections of the power and I/O devices set up.



2.3. INSERTING I/O MODULES

The I/O slots support parallel bus type (high profile I-8K series) and serial bus type (high profile I-87K series) I/O modules. There are more than 60 kinds of module for AI, AO, DI, AO, counter input, frequency input, PWM output, motion control, memory, communication, etc.



For more information about expansion module that are compatible with the ViewPAC, please refer to

http://www.icpdas.com/products/PAC/winpac/io_support_list.htm

Tips & Warnings



It is recommended that the power to the ViewPAC is switched off when wring the I/O module which are plugging in the ViewPAC slots.

Step 1: Read the relevant documentation



The documentation for I-8K series modules is located at:

CD:\ Napdos\io_module

http://www.icpdas.com/products/PAC/winpac/io_support_list.htm

The documentation for I-87K series modules is located at:

CD:\ Napdos\io_module


http://www.icpdas.com/products/PAC/winpac/io_support_list.htm

Step 2: Wiring Connections

All documents include the I/O module specifications, pin assignments and wiring connections.

For example, Pin Assignments and Wiring connections for the I-87054W module are as follows:

Pin Assignments



Terminal No.	Pin Assignment Name
01	DI.COM0
02	DI0
03	DI1
04	DI2
05	DI3
06	DI4
07	DI5
08	DI6
09	DI7
10	D00
11	D01
12	D02
13	D03
14	D04
15	D05
16	D06
17	D07
18	DO.GND
19	DO.GND
20	DO.PWR

Wire Connection

Input Type	ON State LED ON Readback as 1	OFF State LED OFF Readback as 0
Relay Contact	Relay ON	Relay Off
	+ → --- DI.COM --- DIx Relay Close	+ → --- DI.COM --- DIx Relay Open
TTL/CMOS Logic	Voltage < 1V	Voltage > 3.5V
	Logic Power --- DI.COM --- DIx Logic Level Low	Logic Power --- DI.COM --- DIx Logic Level High
NPN Output	Open Collector On	Open Collector Off
	+ → --- DI.COM --- DIx ON	+ → --- DI.COM --- DIx OFF
PNP Output	Open Collector On	Open Collector Off
	+ → --- DI.COM --- DIx ON	+ → --- DI.COM --- DIx OFF
Output Type	ON State LED ON Readback as 1	OFF State LED OFF Readback as 0
Drive Relay	Relay ON	Relay Off
	+ → --- DO.PWR --- DOx --- DO.GND	+ → --- DO.PWR --- DOx --- DO.GND
Resistance Load		
	+ → --- DO.PWR --- DOx --- DO.GND	+ → --- DO.PWR --- DOx --- DO.GND

2.4. MOUNTING THE WATERPROOF

The ViewPAC provides an IP67 waterproof connector which consists of the following components plugged in RJ-45 cable.





Completion

2.5. CONFIGURING THE BOOT MODE

The ViewPAC has five operating modes that can be determined through a rotary switch.

The table below lists the operation mode selection.

Rotary switch position	Modes of operation
0	Normal mode (Default)
1	Safe mode
2	Debug mode
3	OS update mode
4	Development mode
5	DCON_CE
6	VCEP
7 ~ 9	(For user)

Normal mode (Default)

Normal mode is the default mode of operation and the one you will use most of the time. Use this mode for more tasks and configurations. Programs also are executed in this mode.

Safe mode

Safe mode is a trouble shooting. The mode loads the minimum required device drivers and system services to boot the ViewPAC.

If you have malicious software or a program caused the ViewPAC cannot be boot or run the normal mode, you can boot in safe mode to solve the problem.

Tips & Warnings



In normal mode, if the new settings are not saved when you change and save the settings using the ViewPAC Utility, to solve this problem, perform the following steps:


Step 1: Restart the ViewPAC in safe mode

Turn the rotary switch to “1”, and then restart the ViewPAC.





Step 2: Start the ViewPAC Utility to restore the default settings

Start the ViewPAC Utility, and then click the “Restore Default Settings” command and “Save” command from the “File” menu



Step 3: Restart the ViewPAC in normal mode

Turn the rotary switch to “0”, and then restart the ViewPAC.



Debug mode

Debug mode is a special environment in which program debug functions can be used in addition to normal system functions.

Debug mode is unsupported.

OS Update mode

OS update mode is a way used to update OS. To update the ViewPAC OS image, please refer to “6.1. OS updates”

DCON_CE mode

This mode is the same as Normal mode. Besides, DCON_CE.exe will be run automatically after booting

Tips & Warnings



DCON_CE.exe must be placed on the \\System_Disk\\Tools\\DCON_CE, or else DCON_CE.exe cannot be run automatically after booting.

VCEP mode

This mode is the same as Normal mode. Besides, VCEP.exe will be run automatically after booting.

Tips & Warnings



VCEP.exe must be placed on the \\System_Disk\\Tools\\VCEP or else VCEP.exe cannot be run automatically after booting.

User mode

Rotary switch position 7, 8, 9 are reserved for user's applications. When ViewPAC is boot with one of these rotary switch positions, it is boot at normal mode. User's application can check the rotary switch position to run at different mode.

2.6. TESTING THE VIEWPAC

VP-23W1:

ViewPAC combines WinPAC, graphic display and keypad dial in one unit. The ViewPAC Quick Test is a toolkit used to check out the ViewPAC particular function compared with WinPAC.



Audio Options:

Play Audio

Play Audio button is used to check the audio output.

Buzzer Options:

Play Buzzer

Play Buzzer button is used to check the buzzer.


LED Options:

These buttons are used to check LEDs sign.

KeyPAD Option:

Checkboxes are used to check the KeyPAD.

Text field is used to check the input format.



The shift key is a modifier key used to enter alternate upper letters or characters.

VP-25W1:

ViewPAC combines WinPAC, graphic display and keypad dial in one unit. The ViewPAC Quick Test is a toolkit used to check out the ViewPAC particular function compared with WinPAC.



Audio Options:

Play Audio

Play Audio button is used to check the audio output.

Buzzer Options:

Play Buzzer

Play Buzzer button is used to check the buzzer.

LED Options:


These buttons are used to check LEDs sign.

KeyPAD Option:

Checkboxes are used to check the KeyPAD.

LCD Backlight Options:

The slider is used to check the LCD Backlight.



2.7. USING VIEWPAC UTILITY TO MANAGE THE VIEWPAC


The ViewPAC Utility is a toolkit used to quickly control and manage the ViewPAC.

For more detailed information on ViewPAC Utility applications, please refer to
“3.5. ViewPAC Utility”


Step 1: Run the ViewPAC Utility located on desktop



**Step 2: Configure IP address (DHCP),
FTP Server, Auto Execution
files..., etc**




**Step 3: Save and Reboot the
ViewPAC**



2.8. USING DCON UTILITY TO CONFIGURE THE I/O MODULES

DCON Utility is a tool kit used to quickly control and manage expansion I/O modules with DCON protocol.

Step 1: Run the DCON firmware on the ViewPAC controller




The DCON firmware is located at:
\System_Disk\tools\DCON_CE\

Step 2: Run the DCON Utility on the host PC

The DCON Utility can be obtained from:

CD:\Napdos\vp-2000_ce50\PC_Tools\DCON_Utility\

http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/pc_tools/dcon_utility/



Step 4: On the WINCE device connection, enter the IP address of the ViewPAC to search the I-87K series expansion I/O modules




Step 5: It will display a list of I-87K series expansion I/O modules, then select the module name that you want to configure

module	Address	Baudrate	Checksum	format	Status	Description
WinCon8000	1[1]	115200	Disable	N,8,1		WinPAC8000 System(DCON)
xxxxx	S0	115200	Disable			[Parallel bus module] or [None]
xxxxx	S1	115200	Disable			[Parallel bus module] or [None]
xxxxx	S2	115200	Disable			[Parallel bus module] or [None]
xxxxx	S3	115200	Disable			[Parallel bus module] or [None]
xxxxx	S4	115200	Disable			[Parallel bus module] or [None]
xxxxx	S5	115200	Disable			[Parallel bus module] or [None]
xxxxx	S6	115200	Disable			[Parallel bus module] or [None]
xxxxx	S7	115200	Disable			[Parallel bus module] or [None]

3. TOOLS AND TASKS

This chapter briefly describes the functions of the ViewPAC software toolkits.

Following tools has been installed on the ViewPAC.



• DCON_CE

With Host PC running the DCON Utility, on the ViewPAC, the DCON_CE program allows user to view and monitor the status of the DCON Utility.

• ISQLW35

The ISQLW35 implements SQL server compact 3.5 Query Analyzer.

• Modbus

The Modbus provides various applications of Modbus protocol for configuring the ViewPAC.

• NAPOPC_CE5

NAPOPC_CE5 is an integrated omnibus software package, it allows user to quickly establish a DCS control system.

For more information about the NAPOPC_CE5, please refer to “3.2. NAPOPC_CE5”.

• RegistryViewer

The Registry Viewer allows user to view the registry value of Windows CE Operating System.

• Remote display application

The remote display application allows user to view the display remotely of the ViewPAC on a Host PC.

• SendToCOM

The SendToCOM allows user to send/receive data to/from the expansion module via serial port.

• TaskMgr

The TaskMgr provides details about programs and processes running on the ViewPAC.

• VCEP

The VCEP allows user to manage the ViewPAC remotely on a Host PC.


For more information about the VCEP, please refer to “3.4. VCEP (Virtual CE Pro)”.

• ViewPAC Utility

The ViewPAC Utility provides various useful functions such as configuring Ethernet settings, monitoring system settings and FTP services .etc for easy and quick management.

For more information about the ViewPAC Utility, please refer to “3.5. ViewPAC Utility”.

3.1. DCON UTILITY



The DCON Utility is a tool kit that helps users search the network, easily configure the I/O modules and test the I/O status via the serial port (RS-232/485) or Ethernet port (using virtual com port). It supports not only the DCON Protocol I/O modules but also the M Series I/O Modules (Modbus RTU M-7K, M-87K and will support Modbus ASCII M-87K) now.

For more detailed information on ViewPAC Utility applications, please refer to
“2.9. Using DCON Utility to configure the I/O modules”

3.2. NAPOPC_CE5



NAPOPC_CE5 DA Server is a free OPC DA Server (The "OPC" stands for "OLE for Process Control" and the "DA" stands for "Data Access") working on WinPAC, ViewPAC & WinCon controllers provided by ICP DAS Ltd. The first standard (originally called simply the OPC Specification and now called the Data Access Specification)

resulted from the collaboration of a number of leading worldwide automation suppliers working in cooperation with Microsoft. Originally based on Microsoft's OLE COM (component object model) and DCOM (distributed component object model) technologies, the specification defined a standard set of objects, interfaces and methods for use in process control and manufacturing automation applications to facilitate interoperability. NAPOPC_CE5 DA Server integrates OPC, Modbus TCP Slave and Modbus RTU Slave three kind Slave services, as well as integrates Modbus TCP Master, Modbus RTU Master and DCON three kind Master communication protocols. It also provides one advanced function "Rule Script" for use in the I/O integration and transformation, and some conditional Logic operation.


Any version before 2.1.0 of the NAPOPC_CE5 was named "Quicker"

3.3. SENDToCOM

The SendToCOM uses the serial port to communicate with expansion module. To use the SendToCOM, you can send data to expansion module through the serial port, and receive data from other device through the serial port.

For more information about these commands for communicating with expansion module, please refer to:

CD:\Napdos\io_module\87k_high_profile_modules.htm



3.4. VCEP



ICPDAS VCEP is designed for managing your ViewPAC anywhere. No matter where you are, ICPDAS VCEP provides a convenient environment on the Desktop PC and allows you control your ViewPAC remotely.

ICPDAS VCEP is composed of two main components:

The “Server” which runs on ViewPAC.

The “Client” which runs on a Desktop PC.

Once a connection is established between the client and server (initiated by the client), the client will periodically send requests for screen updates and send mouse/key click information to the server to simulate. Each video frame is inter-compressed against the previous frame and then intra-compressed with a modified LZW scheme to minimize the amount of data transmitted from server to client.

For more detailed information on VCEP application, please refer to

http://www.icpdas.com/products/PAC/wincon-8000/wincon_VirtualCE.htm

3.5. VIEWPAC UTILITY


The ViewPAC Utility is a tool which is designed to quickly control and management the ViewPAC.




3.5.1. Menu Bar

The ViewPAC Utility includes the following function menu. All function menus will be explained later.

✓ File Menu




✓ Help Menu



✓ Configuration Menu




File Menu



The menu commands	Use to
Save	Saves the settings into Flash. The new settings don't take effect until the ViewPAC restart.
Save and Reboot	Saves the settings into Flash and restart the ViewPAC. The new settings will take effect after the ViewPAC restart.
Reboot Without Save	Restarts the ViewPAC without save the settings into Flash.
Restore Default Settings	Restarts the settings of ViewPAC to its factory default values. The settings include configuration setting, network setting, auto execution, etc.
Exit	Exits the ViewPAC Utility.

Help Menu



The menu commands	Use to
Reset System to Default	Resets the system interrupt status to default. The operation used in the situation when the interrupt crash. You can select this operation to reset the interrupt status without rebooting the device.
Release Notes	Checks out what's new and the know issues.
About	Displays a dialog box with information about ViewPAC Utility, including the current version and copyright information.

Configuration Menu




The menu commands	Use to
Import Registry Key	<p>Backs up a sub-key of registry by using a registration entry (.reg) file.</p> <p>How to use:</p> <p>Step 1: Select the “Import Registry Key”, then the “Open” dialog box will appear</p> <p>Step 2: On the “Open” dialog box, select a specific .reg file to import</p> <p>Warning:</p> <ol style="list-style-type: none">1. The .reg file which should be saved by “Export Registry Key”.2. It will not save automatically after import a .reg file.
Export Registry Key	<p>Makes a back up of a registry sub-key</p> <p>How to use:</p> <p>Step 1: Select the “Export Registry Key”, then the “Export Registry” box will appear</p> <p>Step 2: Select a specific root key</p> <p>Step 3: Input a specific path of sub-key</p> <p>Step 4: Push the “OK” button, then the “Save As” dialog box will appear prompting you to select a location where you want to save this exported file</p> <p>Warning:</p> <p>The export operation will export all the sub-keys of the specific key which you input.</p>
Store All Registry Setting	<p>Stores all registry setting to flash from .das file which is saved by “Dump All Registry Setting”.</p> <p>How to use:</p>

The menu commands	Use to
	<p>Step 1: Select the “Store All Registry Setting”, then the “Open” dialog box will appear</p> <p>Step 2: On the “Open” dialog box, select a specific .das file to store</p> <p>Warning:</p> <ol style="list-style-type: none"> 1. The .das file which should be saved by “Dump All Registry Setting”. 2. It will save automatically after store .das file.
Dump All Registry Settings	<p>Dump all registries setting to .das file.</p> <p>How to use:</p> <p>Select the “Dump All Registry Setting”, then the “Save As” dialog box will appear prompting you to select a location where you want to save this exported file.</p>

3.5.2. Property Tabs

The ViewPAC Utility includes the following property tabs, all property tabs will be explained later.



- ✓ **System Setting**
- ✓ **Ethernet Setting**
- ✓ **FTP Setting**
- ✓ **System Information**
- ✓ **Auto Execution**
- ✓ **Multi-serial port wizard**
- ✓ **System Memory Setting**
- ✓ **Backplane Compatibility**

System Setting Tab


The System tab provides functions to configure the task bar HTTP directory path.



The tab use to	How to use
Adjust the size of the desktop	Select a display resolution from the Resolution list.
Lock or Auto-Hide the taskbar	Auto-Hide: Select the Auto Hide check box Lock: Select the Always On Top check box.
Check the status of the battery	See the Battery1 and Battery2 field that displays the battery status.
Change the HTTP directory path	Enter a new path in the Change HTTP document root directory \windows\www\wwwsub to field, and then press the Setting button.

Ethernet Setting Tab


The Ethernet Setting tab provides functions to configure either DHCP (Roaming) or manually configured (Static) network settings and to monitor the MAC address. Generally, DHCP is the default settings, but if you don't have a DHCP server, you must configure the network settings by using manual configuration.



The tab use to	How to use
Configure the network settings	Obtaining an IP address automatically from DHCP: Select the Use DHCP to get IP address option. Manually assign an IP address: Select the Assign IP address option.
Monitor the MAC address	See the MAC Address 1 and MAC Address 2 fields that display the physical address of LAN1 and LAN2.

FTP Setting Tab

The FTP Setting tab provides functions to enable/disable the FTP access, enable/disable anonymous FTP access, and configure the FTP directory path.




The tab use to	How to use
Enable or disable the FTP access	Enable: Select the Enable check box in the FTP field. Disable: Select the Disable check box in the FTP field.
Enable or disable anonymous FTP access	Enable: Select the Enable check box in the Allow Anonymous field. Disable: Select the Disable check box in the Allow Anonymous field.
Enable or disable anonymous FTP upload	Enable: Select the Enable check box in the Allow Anonymous Upload field. Disable: Select the Disable check box in the Allow Anonymous

The tab use to	How to use
	Upload field.
Change the FTP directory path	Enter a new path in the Change FTP default download directory field, and then press the Setting button.

System Information Tab

The System Information tab provides functions to monitor necessary system information of the ViewPAC-8000. The system information is the most important note of version control for upgrading system.




Auto Execution Tab

The Auto Execute tab provides functions to configure programs running at ViewPAC-8000 startup, it allows users to configure ten execute files at most.



The allowed file types are .exe and .bat, and they are executed in order of program 1, program 2, etc.



The tab use to	How to use
Configure programs running at startup	Press the Browse button to select the execute file which you want, and then press the Setting button.

Multi-Serial Port Wizard Tab



The Multi-serial port provides functions for installation of the RS-232/RS-422/RS-485 communication module driver.




The table below shows the expansion RS-232/RS-422/RS-485 communication modules that are compatible with the ViewPAC.

Item	RS-232	RS-422/RS-485	Isolation	Connector
I-8112iW	2	-	2500 Vrms	DB-9 x 2
I-8114W	4	-	-	DB-37 x 1
I-8114iW	4	-	2500 Vrms	DB-37 x 1
I-8142iW	-	2	2500 Vrms	Terminator block x 1
I-8144iW	-	4	2500 Vrms	Terminator block x 1


The ViewPAC can be expanded to support up to 16 I/O modules.

For more detailed information about these support modules, please refer to
http://www.icpdas.com/products/Remote_IO/i-8ke/selection_rs232_i8k.htm



System Memory Tab

The SRAM Setting tab provides functions to adjust and monitor the unused RAM.



The tab use to	How to use
Adjust display	Move the slider left to release more memory running programs or move the slider right to release more storage room, and then press the Setting button

4. YOUR FIRST VIEWPAC PROGRAM

This chapter describes the components of the ViewPAC SDK, and provides step by step tutorial for developer that will teach you how to create your first ViewPAC program.

Before writing your first program, ensure that you have the necessary development tools and the corresponding ViewPAC SDKs are installed on your system.

4.1. PREPARING THE DEVELOPMENT TOOLS

There are several programming tools available for application developers targeting Windows CE-based ViewPAC. One of the following tools must be installed on the Host PC.

- ✓ Microsoft eMbedded Visual C++
- ✓ Visual Basic.net
- ✓ Visual C#

4.2. INSTALLING VIEWPAC SDKs

The ViewPAC SDK is a Software Development Kit (SDK) that contains C header files, C libraries and documents.

Below is a step by step procedure for installing the ViewPAC SDKs.

Step 1: Insert the CD into your CD-ROM drive

Step 2: Execute the “PAC270_SDK_YYYYMMDD.msi” which is located in

CD:\Napdos\wp-8x4x_ce50\SDK\

Step 3: Follow the prompts until the installation is complete

4.3. UNDERSTANDING THE VIEWPAC APIs

The ViewPAC SDKs includes several application programming interfaces (APIs) that allows you perform various supporting tasks when developing ViewPAC.

➤ Requirements

The ViewPAC SDK only supports NET Framework 2.0 or above.

➤ Installation Path

After installing the ViewPAC SDKs, a number of functions can be installed on the Host PC, and this installation puts the header files, libraries into the following public places so they are easily changed by update the ViewPAC SDKs.

Header files:


C:\Program Files\Windows CE Tools\wce500\PAC270\lcpdas\Include\ARMV4I\

Libraries:

C:\Program Files\Windows CE Tools\wce500\PAC270\lcpdas\Lib\ARMV4I\

4.3.1. ViewPAC SDK Overview

4.3.1.1. WinPAC Standard API



- **SystemInformation Functions**

Provides reference information for the system status.

- **Backplane Access API**

Provides reference information for the backplane access APIs, including Hot Plug and backplane information.

- **Interrupt API**

Provides reference information for the Interrupt APIs

- **Memory Access API**

Provides reference information for the memory R/W APIs, including EEPROM and SRAM.

- **Watchdog Functions**

Provides reference information for the watchdog APIs, including hardware watchdog and OS watchdog.

- **UART API**

Provides reference information for the UART APIs.

- **Registry API**

Provides reference information for the registry.

- **microSD Management API**

Provides reference information for the microSD Manager.

- **PAC_IO API**


Provides reference information for IO APIs, including local and remote.

In additions, no matter 8K or 87K modules use the same API.

- **Error Handling API**

Provides reference information for error handling.

4.3.1.2. ViewPAC Particular API



- **Backlight Functions**

Provides reference information for the backlight.

- **Buzzer Beep Functions**

Provides reference information for the buzzer.

- **LED Functions**

Provides reference information for the LED


4.3.2. ViewPAC SDK Reference

For full usage information regarding the description, prototype and the arguments of the functions, please refer to the “WinPAC Standard API Manual” and “ViewPAC Particular API Manual” located at:


CD:\Napdos\vp-2000_ce50\Document\SDK_Document

ftp://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/document/sdk_document/

✓ WinPAC Standard API Manual



✓ ViewPAC Particular API Manual



4.4. YOUR FIRST PROGRAM IN C#

To create a demo program with C# development tool includes the following main steps:


1. Create a new project
2. Add project reference for an application
3. Design and Build an application program
4. Execute the application on the ViewPAC

All main steps will be described in the following subsection.


4.4.1. Create a new project

Step 1: Start the Visual Studio 2005

Step 2: On the “File” menu, select the “New” command, and then click the “Project” command




Step 3: In the “New Project” dialog box do the following in this order



Step 4: Click OK to start creating a “SDKinfo” project

4.4.2. Add project reference for an application

Step 1: On the “Solution Explorer” window, right-click the “Reference” and then click the “Add Reference...” command




Step 2: In the “Add Reference” dialog box, select the “Browse” tab, and then specify the directory of the “ViewPACNet.dll” file in the “File name” field

The “ViewPACNet.dll” file can be obtained from:

CD:\Napdos\vp-2000_ce50\SDK\ViewPACNet\


http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/sdk/ViewPACnet/




4.4.3. Design and Build an application program

Step 1: Add a “button” object in the “Form1” dialog box


Step 2: Right-click the “button” object and click the “Properties” command



Step 3: On the “Properties” window, type “Check the SDK version” in the “Text” edit box



Step 4: Right-click the “Form1” dialog box and click the “View Code” command to open the editor window



Step 5: Insert the “using ViewPACNet;” into the header area after “using System.Windows.Forms;”

```
using System;
using System.Linq;
using System.Collections.Generic;
using System.ComponentModel;
using System.Data;
using System.Drawing;
using System.Text;
using System.Windows.Forms;
using ViewPACNet;

namespace SDKinfo
{
    public partial class Form1 : Form
    {
        public Form1()
        {
            InitializeComponent();
        }
    }
}
```

Step 6: In the “Form1” dialog box, double-click the “button” object to open the editor window



Step 7: Insert the following code in the Editor Window

```
MessageBox.Show(pac_GetVIEWSDKVersion());
```


```
namespace SDKInfo
{
    public partial class Form1 : Form
    {
        public Form1()
        {
            InitializeComponent();
        }

        private void button1_Click(object sender, EventArgs e)
        {
            MessageBox.Show(ViewPAC.pac_GetVIEWSDKVersion());
        }
    }
}
```



4.4.4. Execute the application on the ViewPAC

Step 1: On the “Build” menu, click the “Build Solution” command




Step 2: Open the web browser and type the IP address to connect the FTP server of ViewPAC

Step 3: Upload the “SDKinfo.exe” application and the corresponding “ViewPacNet.dll” file to the ViewPAC via the ViewPAC FTP server

Tips & Warnings



For applications programming in C# and VB.net with .net framework, when executing these application on the ViewPAC controller, the corresponding “ViewPACnet.dll” file must be in the same directory as the .exe file



Step 4: On the ViewPAC, execute the uploaded file



4.5. YOUR FIRST PROGRAM IN VB.NET

To create a demo program with C# development tool includes the following main steps:


1. Create a new project
2. Add project reference for an application
3. Design and Build an application program
4. Execute the application on the ViewPAC

All main steps will be described in the following subsection.


4.5.1. Create a new project

Step 1: Start the Visual Studio 2005

Step 2: On the “File” menu, select the “New” command, and then click the “Project” command




Step 3: In the “New Project” dialog box do the following in this order



Step 4: Click OK to start creating a “SDKinfo” project

4.5.2. Add project reference for an application

Step 1: On the “Class View” window, right-click the “Reference” and then click the “Add Reference...” command




Step 2: In the “Add Reference” dialog box, select the “Browse” tab, and then specify the directory of the “ViewPACNet.dll” file in the “File name” field

The “Winpacnet.dll” file can be obtained from:

CD:\Napdos\vp-2000_ce50\SDK\ViewPACNet\


http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/sdk/ViewPACNet/




4.5.3. Design and Build an application program

Step 1: Add a  “button” object in the “Form1” dialog box


Step 2: Right-click the “button” object and click the “Properties” command



Step 3: On the “Properties” window, type “Check the SDK version” in the “Text” edit box



Step 4: In the “Form1” dialog box, double-click the “button” object to open the editor window




Step 5: Insert the following code in the Editor Window

1. Imports ViewPacNet
2. MessageBox(ViewPACNet.pac_GetOSVersion())

```
Imports ViewPacNet
Public Class Form1
    Private Sub Button1_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles Button1.Click
        MessageBox.Show(ViewPAC.pac_GetVIEWSDKVersion())
    End Sub
End Class
```

4.5.4. Execute the application on the ViewPAC

Step 1: On the “Build” menu, click the “Build Solution” command




Step 2: Open the web browser and type the IP address to connect the FTP server of ViewPAC

Step 3: Upload the “SDKinfo.exe” application and the corresponding “ViewPacNet.dll” file to the ViewPAC via the ViewPAC FTP server

Tips & Warnings



For applications programming in C# and VB.net with .net framework, when executing these application on the ViewPAC controller, the corresponding “ViewPACnet.dll” file must be in the same directory as the .exe file



Step 4: On the ViewPAC, execute the uploaded file



4.6. YOUR FIRST PROGRAM IN EMBEDDED VISUAL C++

To create a demo program with eMbedded Visual C++ development tool includes the following main steps:


1. Create a new Forms-Based project
2. Configure compiler options
3. Design and Build an application program
4. Execute the application on the ViewPAC

All main steps will be described in the following subsection.


4.6.1. Create a new Forms-Based project

Step 1: Start the Microsoft Embedded Visual C++

Step 2: From the “File” menu, click the “New” command




Step 3: In the “New” dialog, select the “Projects” tab and do the following in this order



Tips & Warnings




The selected CPU type must have “Win32 [WCE ARMV4I]”




Step 4: Click the “OK” button to start the wizard


Step 5: On the first page of the wizard, select “Dialog based” option and then click the “Next” button to the next step




Step 6: On the next page of the wizard, leave all the options as they are, and then click the “Next” button to the next step




Step 7: On the next page of the wizard, leave all the options as they are, and then click the “Next” button to the next step



Step 8: On the next page of the wizard, leave all the options as they are, and then click the “Finish” button to complete the wizard




Step 9: The final summary appears, click the “OK” button to exit the wizard




4.6.2. Configure compiler options

On the WCE configuration toolbar, select the “Win32 [WCE ARMV4] Release”




4.6.3. Specify the path for project reference

Step 1: Click the “Options...” command from the “Tools” menu



Step 2: In the “Option” dialog, select the “Directories” tab and do the following in this order to specify the header file include path




The “ViewpacSDK.h” file can be obtained from:

CD:\Napdos\vp-2000_ce50\SDK\ViewpacSDK\

http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/sdk/viewpacSDK/

Step 3: In the “Option” dialog, select the “Directories” tab and do the following in this order to specify the library file path




The “ViewPACSDK.lib” file can be obtained from:


CD:\Napdos\vp-2000_ce50\SDK\ViewpacSDK\

http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/sdk/viewpacsdk/

Step 4: Click the “Settings...” command from the “Project” menu



Step 5: In the “Project Settings” dialog box do the following in this order




4.6.4. Design and Build an application program


Step 1: On the “Workspace” window, select the “ResourceView” tab and expand the “dialog” folder, and then double-click the “IDD_DEMO_DIALOG” to open the dialog box




Step 2: Add the “button” object in the “SDKinfo” dialog box



Step 3: In the “SDKinfo” dialog box, right-click the button object and then click the “Properties” command



Step 4: Type the “Check the SDK version” in the “Caption” edit box and then click the “close” button



Step 5: In the “SDKinfo” dialog box, double-Click the button object



**Step 6: Type the “OnBtnCheckSDK” in the “Member function name” edit box
and then click the “OK” button**



Step 7: Insert the following code into the Editor Window

```
char SDK[32];
TCHAR buf[32];
pac_GetVIEWSDKVersion(SDK);
pac_AnsiToWideString(SDK, buf);
MessageBox(buf,NULL,MB_OK);

    return TRUE; // return TRUE unless you set bOk to FALSE
}

void CSDKinfoDlg::OnBtnCheckSDK()
{
    // TODO: Add your control notification handler
    char SDK[32];
    TCHAR buf[32];
    pac_GetVIEWSDKVersion(SDK);
    pac_AnsiToWideString(SDK,buf);
    MessageBox(buf,NULL,MB_OK);
}
```



Step 8: Insert the “#include “ViewpacSDK.h” and #include “winpacSDK.h”” into the header area

```
// SDKinfoDlg.cpp : implementation file
//

#include "stdafx.h"
#include "SDKinfo.h"
#include "SDKinfoDlg.h"


#include "ViewpacSDK.h"
#include "winpacSDK.h"

#ifndef _DEBUG
#define new DEBUG_NEW
#undef THIS_FILE
static char THIS_FILE[] = __FILE__;
#endif

// CSDKinfoDlg dialog
```


4.6.5. Execute the application program on ViewPAC

Step 1: On the “Build” menu, click the “Build systeminfo.exe” command



Step 2: Open the web browser and type the IP address to connect the FTP server of ViewPAC

Step 3: Upload the “SDKInfo.exe” application to the ViewPAC via the ViewPAC FTP server



Step 4: On the ViewPAC, execute the uploaded file



5. APIs AND DEMO REFERENCES


This chapter introduces demo programs that have been designed for the ViewPAC. You can examine the demo source code, which includes numerous comments, to familiarize yourself with the ViewPAC API. This will allow developing your own applications quickly by modifying these demo programs. The following details the contents of the ViewPAC demo programs.

5.1. DEMO PROGRAMS WITH C#

The table below describes the ViewPAC demos that have been designed to demonstrate the standard operation features of the ViewPAC.

5.1.1. C# Demo program for WinPAC Standard API

The table below describes the ViewPAC demos that have been designed to demonstrate the standard operation features of the ViewPAC.



Folder	Demo	Explanation
system	systeminfo	Retrieves information about the OS version, CPU version, SDK version, etc.
backplane	backplaneinfo	Retrieves information about the DIP switch, backplane ID and slot count.
memoryaccess	memory	Shows how to read/write date values from/to EEPROM
	battery_backup_sram	Shows how to read or write to the battery backup
watchdog	watchdog	Displays how the watchdog operate
microsd	microsd_management	Shows how to enables/disables Micro SD
registry	registry	Shows how to read/write date values from/to registry
UART	diag	Shows how to read the name of local I/O modules via UART


For C# application, these demo programs can be obtained from:

CD:\Napdos\wp-8x4x_ce50\Demo\WinPAC\DotNET\C#.NET\Standard\

ftp://ftp.icpdas.com/pub/cd/winpac/napdos/wp-8x4x_ce50/demo/winpac/dotnet/c%23.net/standard/

5.1.2. C# Demo program for PAC IO API

The table below describes the ViewPAC demos that have been designed to demonstrate the expansion I/O module features of the ViewPAC.



Folder	Demo	Explanation
Local	find_io	Shows how to retrieve the module names and types which plugged in the ViewPAC.
	8k_di	Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules.

Folder	Demo	Explanation
Local	8k_do	Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules.
	8k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 8K series DIO modules.
	87k_basic	Shows how to send/receive a command/response application. This demo program is used by 87K series modules.
	87K_demo	Shows how use UART API and the IO modules located as slots. This demo program is used by 87K series modules.
	87k_ai	Shows how to read the AI values of AI module. This demo program is used by 87K series AI modules.
	87k_ao	Shows how to write the AO values to AO module. This demo program is used by 87K series AO modules.
	87k_di	Shows how to read the DI values of DI module. This demo program is used by 87K series DI modules.
	87k_do	Shows how to write the DO values to DO module. This demo program is used by 87K series DO modules.
	87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 87K series DIO modules.
Remote	7k87k_basic	Shows how to send/receive a command/response application. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_ai	Shows how to read the AI values of AI module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_ao	Shows how to write the AO values to AO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_di	Shows how to read the DI values of DI module.

Folder	Demo	Explanation
		This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_do	Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.


For C# application, these demo programs can be obtained from:

CD:\Napdos\wp-8x4x_ce50\Demo\WinPAC\DotNET\C#.NET\PAC_IO\

ftp://ftp.icpdas.com/pub/cd/winpac/napdos/wp-8x4x_ce50/demo/winpac/dotnet/c%23.net/pac_io/

5.1.3. C# Demo program for ViewPAC Particular API

The table below describes the ViewPAC demos that have been designed to demonstrate the particular features of the ViewPAC.



Folder	Demo	Explanation
BuzzerBeep	BuzzerBeep	Shows how to make a simple buzzer beep.
KeyPad	KeyPad	Shows how the KeyPad operates.
LCDBackLight	LCDBackLight	Shows how to control the LCD backlight.
Led	Led	Shows how to control the LEDs.
PlaySound	PlaySound	Shows how to control the microphone-in and earphone-out.

For C# application, these demo programs can be obtained from:

CD:\Napdos\vp-2000_ce50\Demo\ViewPAC\DotNET\C#.NET\


ftp://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/demo/viewpac/dotnet/c%23.net/

5.2. DEMO PROGRAMS WITH eMBEDDED VISUAL C++

Examples are good way to understand the ViewPAC SDK. The table below describes ViewPAC demos and covers most of the common usages of each ViewPAC API for using eMbedded Visual C++.

5.2.1. eVC Demo program for WinPAC Standard API

The table below describes the ViewPAC demos that have been designed to demonstrate the standard operation features of the ViewPAC.



Folder	Demo	Explanation
system	systeminfo	Retrieves information about the OS version, CPU version, SDK version, etc.
backplane	backplaneinfo	Retrieves information about the DIP switch, backplane ID and slot count.
memoryaccess	memory	Shows how to read/write date values from/to EEPROM
	battery_backup_sram	Shows how to read or write to the battery backup
watchdog	watchdog	Displays how the watchdog operate
microsd	microsd_management	Shows how to enables/disables Micro SD
registry	registry	Shows how to read/write date values from/to registry
UART	diag	Shows how to read the name of local I/O modules via UART


For C# application, these demo programs can be obtained from:

CD:\Napdos\wp-8x4x_ce50\Demo\WinPAC\DotNET\C#.NET\Standard\

ftp://ftp.icpdas.com/pub/cd/winpac/napdos/wp-8x4x_ce50/demo/winpac/dotnet/c%23.net/standard/

5.2.2. eVC Demo program for PAC IO API

The table below describes the ViewPAC demos that have been designed to demonstrate the expansion I/O module features of the ViewPAC.



Folder	Demo	Explanation
Local	find_io	Shows how to retrieve the module names and types which plugged in the ViewPAC.
	8k_di	Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules.
	8k_do	Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules.

Folder	Demo	Explanation
Local	8k_dio	<p>Shows how to read the DI and the DO values of the DIO module.</p> <p>This demo program is used by 8K series DIO modules.</p>
	87k_basic	<p>Shows how to send/receive a command/response application.</p> <p>This demo program is used by 87K series modules.</p>
	87K_demo	<p>Shows how use UART API and the IO modules located as slots.</p> <p>This demo program is used by 87K series modules.</p>
	87k_ai	<p>Shows how to read the AI values of AI module.</p> <p>This demo program is used by 87K series AI modules.</p>
	87k_ao	<p>Shows how to write the AO values to AO module.</p> <p>This demo program is used by 87K series AO modules.</p>
	87k_di	<p>Shows how to read the DI values of DI module.</p> <p>This demo program is used by 87K series DI modules.</p>
	87k_do	<p>Shows how to write the DO values to DO module.</p> <p>This demo program is used by 87K series DO modules.</p>
	87k_dio	<p>Shows how to read the DI and the DO values of the DIO module.</p> <p>This demo program is used by 87K series DIO modules.</p>
Remote	7k87k_basic	<p>Shows how to send/receive a command/response application.</p> <p>This demo program is used by 7K or 87K series AI modules which connected through a COM port.</p>
	7k87k_ai	<p>Shows how to read the AI values of AI module.</p> <p>This demo program is used by 7K or 87K series AI modules which connected through a COM port.</p>
	7k87k_ao	<p>Shows how to write the AO values to AO module.</p> <p>This demo program is used by 7K or 87K series AI modules which connected through a COM port.</p>
	7k87k_di	<p>Shows how to read the DI values of DI module.</p> <p>This demo program is used by 7K or 87K series AI modules which connected through a COM port.</p>

Folder	Demo	Explanation
	7k87k_do	Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.


For C# application, these demo programs can be obtained from:

CD:\Napdos\wp-8x4x_ce50\Demo\WinPAC\DotNET\C#.NET\PAC_IO\

ftp://ftp.icpdas.com/pub/cd/winpac/napdos/wp-8x4x_ce50/demo/winpac/dotnet/c%23.net/pac_io/

5.2.3. eVC Demo program for ViewPAC Particular API

The table below describes the ViewPAC demos that have been designed to demonstrate the particular features of the ViewPAC.



Folder	Demo	Explanation
BuzzerBeep	BuzzerBeep	Shows how to make a simple buzzer beep.
KeyPad	KeyPad	Shows how the KeyPad operate.
LCDBackLight	LCDBackLight	Shows how to control the LCD backlight.
Led	Led	Shows how to control the LEDs.
PlaySound	PlaySound	Shows how to control the microphone-in and earphone-out.

For C# application, these demo programs can be obtained from:

CD:\Napdos\vp-2000_ce50\Demo\ViewPAC\DotNET\C#.NET\


ftp://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/demo/viewpac/dotnet/c%23.net/

6. VIEWPAC UPDATES

This chapter provides instructions on how to upgrade ViewPAC OS and SDK.

ICP DAS will continue to add additional features to ViewPAC SDK and OS in the future, so we advise you to periodically check the ICP DAS web site for the latest updates.

ViewPAC updates services can be divided into the following two main categories:



6.1. OS UPDATES


The updates files of OS image are located on:

VP-23W1:

CD:\Napdos\vp-2000_ce50\OS_image\vp-23w1\

VP-25W1:

CD:\Napdos\vp-2000_ce50\OS_image\vp-25w1\




There are two different ways of ViewPAC OS image updates:

i. ViewPAC OS updates from file


(We recommend that you use this method for quick and easy to update ViewPAC OS image)

ii. ViewPAC OS updates from eshell



The ViewPAC OS supports multi-language:

- i. en- English
- ii. sc- Simplified Chinese
- iii. tc- Traditional Chinese




6.1.1. Updating the Boot Loader and the ViewPAC OS image from files

There are two different ways of ViewPAC OS image update:

- i. ViewPAC OS updates from files (Please refer to this section)


We recommend that you use this method for quick and easy to update the ViewPAC OS image

- ii. ViewPAC OS updates from eshell tool (Please refer to section “6.1.2. Updating the ViewPAC OS image from eshell”)



Step 1: Get the latest version of the execute file and the corresponding “autoinit.bat” file and run it on the ViewPAC side

Each folder contains an execute file and a corresponding “autoinit.bat” file.



Step 2: Get the latest version of the installation package and download it to ViewPAC, then execute it

For VP23W1:

The latest version of the installation package can be obtained from:

CD:\Napdos\vp-2000_ce50\os_image\vp-23w1\update_from_file\
http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/os_image/vp-23w1/update_from_file/



For VP25W1:

The latest version of the installation package can be obtained from:

CD:\Napdos\vp-2000_ce50\os_image\vp-25w1\update_from_file\
http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/os_image/vp-25w1/update_from_file/



There are several ways to download the installation package to ViewPAC:

On the ViewPAC, you can download the installation package via an Ethernet connection.


On the host PC, you can download the installation package to ViewPAC via a USB storage device, the removable Micro SD card or FTP server.

The latest version of the ViewPAC OS image file can be obtained from:

CD:\Napdos\wp-8x4x_ce50\OS_image\update_from_file\

http://www.icpdas.com/products/PAC/ViewPAC/download/ViewPAC_8000/download_os_images.htm


Step 3: After execute the installation package, the “Warning !” dialog will display, then click the “OK” button to start the update instructions




Step 4: On the main dialog, click the “Update Now” button



Step 5: On the “Warning !” dialog, click the “Yes” button



Step 6: On the main dialog, click the “Update Now” button to start installation




Tips & Warnings



Please never turn the ViewPAC off during OS load. Besides we recommend you turn off all other application before updating.

The installation will perform the following tasks:



i. Install Boot Loader file

Important Warning



Be careful, if the boot loader broken off in this step and cannot restart in safe mode, you have to send it back to us.

ii. Erase flash disk

iii. Install OS image


iv. Set registry settings to default

Tips & Warnings




This step will reset the registry settings to default, all of your before settings will lost.

Step 7: After completing the above-mentioned tasks, the “Warning !” dialog will appear as follow, after clicking “OK” button to finish updating OS image, be sure the ViewPAC at normal mode



Step 8: Check the View PAC OS version

Start the WinPAC Utility, and then select the “System Information” tab to check the current OS version.





6.1.2. Updating the ViewPAC OS image from eshell

There are two different ways of ViewPAC OS image update:

- i. ViewPAC OS updates from files (Please refer to this section)

We recommend that you use this method for quick and easy to update the ViewPAC OS image

- ii. ViewPAC OS updates from eshell tool (Please refer to section “6.1.2. Updating the ViewPAC OS image from eshell”)



By default, the OS update from Host PC to ViewPAC via Ethernet. Therefore, to update the OS image, make sure Ethernet is connected to the PC.


Step 1: Get the latest version of the ViewPAC OS image

For VP23W1:

The latest version of the installation package can be obtained from:

CD:\Napdos\vp-2000_ce50\os_image\vp-23w1\update_from_Eshell\

http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/os_image/vp-23w1/update_from_Eshell/




For VP25W1:

The latest version of the installation package can be obtained from:

CD:\Napdos\vp-2000_ce50\os_image\vp-25w1\update_from_Eshell\

http://ftp.icpdas.com/pub/cd/winpac/napdos/vp-2000_ce50/os_image/vp-25w1/update_from_Eshell/



Step 2: Run the ESHELL software on the Host PC



ESHELL you can be obtained at:

CD:\Napdos\wp-8x4x_ce50\PC_Tools\Eshell\

ftp://ftp.icpdas.com/pub/cd/ViewPAC/napdos/wp-8x4x_ce50/pc_tools/eshell/


Step 3: Reboot the ViewPAC at update OS mode

Turn the rotary switch to “3”, and then reboot the ViewPAC.




Step 4: Select the device which you want to update the OS image


After starting the ESHELL software, the “Select Device” dialog will appear, then select the device which you want.



Step 5: Select the latest version of the OS image




Step 6: Once the procedure is completed, the “Warning !” dialog box will appear on ViewPAC screen as below shown, before clicking the “Yes” button, you must first turn the rotary switch to the “0” position



Step 7: Check the ViewPAC OS version


Start the WinPAC Utility, and then select the “System Information” tab to check the current OS version.



6.2. SDKs UPDATES

The updates files of SDK image are located on:

CD:\Napdos\vp-2000_ce50\SDK\



By eVC and donet development tools, the ViewPAC SDK installation is divided into the following two parts:

By eVC and donet development tools, the WinPAC SDK installation is divided into the following two parts:

- i. WinPAC SDK updates for dotnet
- ii. WinPAC SDK updates for eMbedded Visual C++

6.2.1. WinPAC SDK updates for C# or VB.net

To determine the SDK version that is compatibly running on the WinPAC, you can read the “Release Note” which is located under each SDK folder, these files provides important updated information for what we fixed and added.

Step 1: Get the latest version of the C# or VB.net components

The latest version of the C# or VB.net components can be obtained from:

ftp://ftp.icpdas.com/pub/cd/WinPAC/napdos/wp-8x4x_ce50/sdk/WinPACNet/

Step 2: Copy the latest version of DLL to Host PC and WinPAC

The DLL files on Host PC are located at anywhere only the solution can reference it.

The DLL files on WinPAC are located at the same directory as the .exe file.

6.2.2. WinPAC SDK updates for eMbedded Visual C++

To determine the SDK version that is compatibly running on the WinPAC, you can read the “Release Note” which is located under each SDK folder, these files provides important updated information for what we fixed and added.

Step 1: Get the latest version of the eMbedded Visual C++ components

The latest version of the eMbedded Visual C++ components can be obtained from:

ftp://ftp.icpdas.com/pub/cd/WinPAC/nadpos/wp-8x4x_ce50/sdk/WinPACSDK/

Step 2: Copy the latest version of header files and libraries to Host PC

The header files are located at:

C:\Program Files\Windows CE Tools\wce500\PAC270\Include

The libraries are located at:

C:\Program Files\Windows CE Tools\wce500\PAC270\Lib

Step 3: Copy the latest version of DLL files to WinPAC

The DLL files are located at:

\System_Disk\ICPDAS\System

7. VIEWPAC DOWNLOAD CENTER

This chapter introduces the WinPAC-8000 Download Center.

Visit the ViewPAC Download Center:

http://www.icpdas.com/products/PAC/viewpac/download/viewpac/download_os_images.htm

The screenshot shows the 'ViewPAC Download Center' page. At the top, there's a note about software compatibility and download instructions. Below that is a navigation bar with tabs: OS images, SDK, Utility & Tools, Demo, Documents, and System Disk. The 'Utility & Tools' tab is selected, displaying the 'ViewPAC Utility' section. This section includes a table with version information and download links for HTTP and FTP. A descriptive text below the table explains the utility's function.

ViewPAC Utility			HTTP	FTP
Version	Last update	Compatibility		
2.0.0.8	Jun. 2009	VP-23Wx / VP-25Wx		

Tools to save / view the system information registry and setup the HTTP / FTP path and update non-volatile internal memory within ViewPAC

The following update categories are available from the ViewPAC Download Center.

- ✓ **OS images** Includes updates and the latest version of ViewPAC OS.
- ✓ **ViewPAC SDK** Includes updates and the latest version of each ViewPAC component SDK, such as ViewPAC SDK, NAPOPC_CE5 SDK, Modbus SDK, etc.
- ✓ **Utility & Tools** Includes updates and the latest version for ViewPAC toolkits
- ✓ **Demo** Includes all related ViewPAC demos.
- ✓ **Documents** Includes updates and the latest version for related ViewPAC documents.
- ✓ **System Disk** Includes updates and the latest version for ViewPAC toolkits

Appendix A. I-8K and I-87K Modules

There are 3 slot options to expand local I/O. And the I/O modules can be parallel bus type (high profile I-8K series) and serial bus type (high profile I-87K series).

The difference between them is


Item	I-8K Series	I-87K Series
Communication interface	Parallel bus	Serial bus
Protocol	-	DCON
Communication speed	Fast	Slow
DI latched function	-	Yes
Counter input (for digital input module)	-	Yes (100 Hz)
Power on value	-	Yes
Safe value	-	Yes
Programmable slew-rate for AO module	-	Yes

Appendix B. Application of RS-485 Network

The RS-485 length can be up to 4000 ft or 1.2 km over a single set of twisted-pair cables, if the RS-485 network is over 4000 ft or 1.2Km, the RS-485 repeater must be added to extend the RS-485 network.


B.1. BASIC RS-485 NETWORK

The basic component of the RS-485 network consist of a Master Controller (or using a PC as a host controller), and some RS-485 devices.




B.2. DAISY CHAIN RS-485 NETWORK

All RS-485 devices are wired directly to the main network. If the network is up to 1.2 km, it will need a repeater (7510 series) to extend the network length.




B.3. STAR TYPE RS-485 NETWORK

There are branches along the main network. In this case, it is better to have a repeater to isolate or filter the noise that is made by devices.




There is a better choice to use 7513 as a RS-485 hub on start type network.



B.4. RANDOM RS-485 NETWORK

There are branches along the main wire. In this case, it is better to have a repeater to isolate or filter the noise that is made by devices.




B.5. MASTER/SLAVES SETTINGS


There must exist one master to have a pull-high/pull-low resistor in the same network. In a master/slave applications, “Master” is the default configuration of ViewPAC.

B.5.1. ViewPAC as a Master (default):

When one of ViewPAC is set to the master mode, then all the other devices on the same network must be set to the slave mode.

Set an ViewPAC to the master mode by adjusting the jumpers on the power board of ViewPAC (the pull-high/pull-low resistors are adjusted to be enabled.) Refer to the following figure:







B.5.2. ViewPAC as a Slave:


For most of application, only one 7520 series module is used as RS-232/485 converter, and its pull-high/pull-low resistors are set to be enabled. Then the ViewPAC and all the other devices on this network must be in their slave mode (the pull-high/pull-low resistors must be disabled).

Please refer to the following figure to set the jumpers to the slave mode. The jumpers are located at the power board of ViewPAC





If there are repeaters on the RS-485 network, you can see that there are pull-high/pull-low resistors on both sides of the repeaters (i-7510)




Appendix C. Tips – How to

C.1. HOW TO ESTABLISH A NEW TELNET AND FTP ACCOUNT

To establish a new telnet and FTP account, please perform the following steps:

Step 1: Open a MS-DOS command prompt



Step 2: Establish a new account

[Syntax] usrmgr –a <username> <password>

The screenshot shows a command-line interface titled "Pocket CMD v 5.0". The menu bar includes "File", "Edit", and "Help". The main window displays the command "usrmgr -a guest 1234" entered at the prompt. The text "1>" is visible before the command.

Tips & Warnings



For more information about managing accounts, you just type “usrmgr” command to get a complete list of supported commands.

The setting may not save. That is, after rebooted, the setting will disappear and you should set the account again.


The screenshot shows a command-line interface titled "Pocket CMD v 5.0". The menu bar includes "File", "Edit", and "Help". The main window displays the command "usrmgr" followed by its usage information. The usage details include options for adding or updating users (-a), removing users (-d), listing users (-l), creating groups (-gm), deleting groups (-gd), listing groups (-gl), listing group members (-gm), adding users to groups (-gat), and removing users from groups (-grf). The text "1>" is visible before the command.

C.2. HOW TO ONLINE DEBUG ViewPAC


Debugging is a process that you use to find and resolve errors, or bugs, in a program.

C.2.1. Debug ViewPAC programs in EVC++


Step 1: On the “Tools” menu, click “Configure Platform Manager...” command




Step 2: On the “Windows CE Platform Manager Configuration” dialog, click the “Properties...” button




Step 3: On the “Device Properties” dialog, click the “Configure...” button




Step 4: On the “TCP/IP Transport Configuration” dialog, select the “Fixed port” check box, and then click the “OK” button




Step 5: On the “Windows CE Platform Manager Configuration” dialog, click the “Test” button




Step 6: The “Manual Server - Action” dialog will appear displaying a command line, before click the “OK” button to close dialog, turn to the ViewPAC controller side to do the next two-steps




Step 7: On the ViewPAC controller side, select  the “Start” menu, and then click the “Run...” command



Step 8: On the “Run” dialog, type the command which displays in step 5 and then click the “OK” button




Step 9: Return to the Host PC side, on the “Manual Server – Action” dialog, click the “OK” button




Step 10: On the “Testing Device Connection” dialog, click the “OK” button




Step 11: On the “Device Properties” dialog, click the “OK” button




Step 12: On the “Windows CE platform or device to configure” dialog, click the “OK” button



Step 13: On the “Build” menu, select the “Start Debug” command and then click the “Go” command




Step 14: The “Manual Server - Action” dialog will appear displaying a command line, before click the “OK” button to close dialog, turn to the ViewPAC controller side to do the next two-steps




Step 15: On the ViewPAC controller side, select the and then click the “Run...” command




“Start” menu,




Step 16: On the “Run” dialog, type the command which displays in step 5 and then click the “OK” button



Step 17: Return to the Host PC side, on the “Manual Server – Action” dialog, click the “OK” button



Step 18: On the “Manual Server - Action” dialog, click the “OK” button




Step 19: Connection established. Then you can debug on line.

Tips & Warnings



If you want to quit the debugger and return to editing, you can click the “Stop Debugging” button from “Debug” menu



C.2.2. Debug ViewPAC programs in Visual Studio 2005/2008

Debugging in Visual Studio 2005/2008 are provided by ViewPAC OS image V 1.3.0.4 or later.


Step 1: Make sure the following file are listed with the matching version numbers

Path	File
C:\Program Files\Common Files\Microsoft Shared\CoreCon\1.0\Bin	1. ActiveSyncBootstrap.dll 2. ConMan2.dll 3. ConManPS.dll 4. DesktopDMA.dll 5. eDbgTL.dll 6. TcpConnectionC.dll
C:\Program Files\Common Files\Microsoft Shared\CoreCon\1.0\Bin\1033	conmanui.dll
C:\Program Files\Common Files\Microsoft Shared\CoreCon\1.0\Target\wce400\armv4i	1. DeviceDMA.dll 2. eDbgTL.dll 3. TcpConnectionA.dll 4. clientshutdown.exe 5. CMAccept.exe 6. ConmanClient2.exe


Step 2: If the version matches correctly and the entire file are there, copy the following files to ViewPAC :\ System_Disk\ICPDAS\System folder

- ✓ Clientshutdown.exe
- ✓ ConmanClient2.exe
- ✓ CMAccept.exe
- ✓ eDbgTL.dll
- ✓ TcpConnectionA.dll


Step 3: On the “Project” menu, click “[Project Name] Properties...” command




Step 4: On the “SystemInfo*” tab, unselect “Deploy the latest version of the .NET compact Framework (including Service Packs)” check box




Step 5: On the “Tools” menu, click “Options...” command




Step 6: On the “Options” dialog, select “PAC 270” from the “Show devices platform” list, and then click the “Properties...” button




Step 7: On the “CAYMAN-ARMV4I_Release Properties” dialog, click the “Configure...” button




Step 8: On the “Configure TCP/IP Transport” dialog, select the “Use specific IP address” option and type the IP address of ViewPAC, and then click the “OK” button




Step 9: On the “CAYMAN-ARMV4I_Release Properties” dialog, click the “OK” button




Step 10: On the “Options” dialog, click the “OK” button



**Step 11: On the ViewPAC controller side, run the “CommandClient2” and the “CMAccept.exe” applications which is located at:
\\System_Disk\\ICPDAS\\System**




Step 12: On the “Tools” menu, click “Connect to Device...” command



Step 13: On the “Connect to Device” dialog, select “PAC 270” from “Platform” list and then click the “Connect” button




Step 14: On the “Tools” menu, click “Connect to Device...” command



Step 15: Connection established. Then you can debug on line.



FAQ:

If the connection fails shown as follow, return to step 11 to do the action below



Open the command prompt, run the

"CommandClient2.exe/transport:tcpconnectiona.dll/property:port=5000/id:Con" at: \System_Disk\ICPDAS\System, and then run the
"CMAccept.exe"



C.3. HOW TO RECOMPILE WINCON PROGRAMS

To recompile Wincon programs to run on ViewPAC, certain components of the programs require adjustments that divides into two parts:

1. Compiler old programs which ran on Wincon 8x3x and 8x4x
2. Modify .vcf file to upgrade the old WinCon project

Tips & Warnings




In general, you only need to do part 1, after this, if the program still can't be compiled to an application, the part 2 just need to do.


C.3.1. Compiler old programs which ran on Wincon 8x3x and 8x4x

Step 1: Open project which programmed in WinCon using eMbedded Visual C++


Step 2: On the “Build” menu, click “Configurations” command




Step 3: Make sure the CPU type is “STANDARDSDK”




Step 4: On the “Configurations” dialog, click the “Add...” button




Step 5: On the “Add Project Configuration” dialog, choose one of the CPU type and then click the “OK” button.




Step 6: On the “Project” menu, click “Settings...” command




Step 7: On the “Project Settings” dialog, select the “Link” tab and change the value of the “Entry-point symbol” field, “WinMainCRTStartup” to “wWinMainCRTStartup”,




Step 8: After performing above-mentioned steps, build the project, your project should build success. If not, it will show error message as follow.
Please continue with the following steps



Step 9: On the “Project” menu, click “Settings...” command



Step 10: On the “Project Settings” dialog, select the “Link” tab and change the value of the “Project Options” field, “ARM” to “THUMB”, and then built the project



C.3.2. Modify .vcf file to upgrade the old WinCon project

Step 1: Open a text editor to modify the .vcf file

Step 2: In the .vcf file, replace “0xa301” with “0xa501”

Step 3: In the .vcf file, replace “ARMV4” with “ARMV4I”

Step 4: In the .vcf file, replace “MACHINE:ARM” with “MACHINE:THUMB”

Step 5: Save the .vcf file just edited

Step 6: Open the old WinCon project and recompile it

C.4. HOW TO USE THE PRINTER

ViewPAC have ability to access the printer, you can connect to the printer via Ethernet network or USB.

Tips & Warnings




ViewPAC only supports HP Laser Jet Printers which support PCL6 driver.

C.4.1. How to use network printer


To use a shared network printer, please perform the following steps:

Step 1: On the Host PC, check the name of the Host PC and the shared printer



Step 2: On the ViewPAC, open a WordPad format file


Step 3: On the ViewPAC, open a WordPad format file



Step 2: Set up the printer

1. Printer: PCL Laser
2. Port: Network
3. Net Path: \ServerName\PrinterName
The “ServerName” is your PC’s name or IP.
The “PrinterName” is your printer’s shared name of your PC
4. Paper Size: Select the paper size


Test !!!



C.4.2. How to use printer via USB


To use a shared network printer via USB, please perform the following steps:

Step 1: On the ViewPAC, open a WordPad format file



Step 2: Set up the printer


1. Printer: Hewlett-Packard LaserJet
2. Port: LPT1
3. Paper Size: Select the paper size



C.5. HOW TO USE SERVICES TOOL

The services tool can help you turn on, turn off and monitor the WinCE services.

Step 1: Open a MS-DOS command prompt



Step 2: List all services

[Syntax] services list

```
File Edit Help
Pocket CMD v 5.0
\> services list
NFY0: 0x00030110      NOTIFY.Dll      Running
HTPO: 0x00031570      HTTPD.DLL      Running
CRDO: 0x00032070      credsrv.dll    Running
MMQ1: 0x00036790      MSMQD.Dll     Off
OBX0: 0x00036b20      OBEXSrVr.dll   Off
FTPO: 0x00037770      FTPD.Dll      Running
TELO: 0x00037ac0      TELNETD.Dll   Running
SMBO: 0x0003c3e0      smbserver.dll  Running
NTPO: 0x0003ffff0     timesvc.dll   Running
\>
```

Step 3: Type the commands to configure service

[Syntax] services stop <services name>

For example, turn on the “FTP” service:

services stop FTPO:

```
File Edit Help
Pocket CMD v 5.0
\> services stop FTPO:
\> services list
NFY0: 0x00030110      NOTIFY.Dll      Running
HTPO: 0x00031570      HTTPD.DLL      Running
CRDO: 0x00032070      credsrv.dll    Running
MMQ1: 0x00036790      MSMQD.Dll     Off
OBX0: 0x00036b20      OBEXSrVr.dll   Off
FTPO: 0x00037770      FTPD.Dll      Off
TELO: 0x00037ac0      TELNETD.Dll   Running
SMBO: 0x0003c3e0      smbserver.dll  Running
NTPO: 0x0003ffff0     timesvc.dll   Running
\>
```

Tips & Warnings



For more information about using services tool, you just type
“services help”

```
File Edit Help
Pocket CMD v 5.0
\> services help
Commands:
    help - print this text
    list - lists loaded services
    load <service name> - activates a service that is inactive
    stop <service instance> stops/pauses a service (does not unload)
    start <service instance> - starts/resumes a service
    refresh <service instance> - causes service to refresh its configuration
    unload <service instance> - causes service to be unloaded and removed
    register <service name> - service will be automatically loaded at next reboot
    unregister <service name> - service will not be automatically loaded at next reboot
    command <service name> [arg1 arg2 ...] - send service-specific command to service
    help <service name> - get information on what service-specific commands are supported

    <service name> - service's name in the registry (i.e. HTTPD)
    <service instance> - particular instantiation (i.e. HTTP0:)

Flags:
    -f <file name>
    -s silent
    -d output to debugger
\> ■
```

Appendix D. Revision History

Revision	Date	Description
1.0.1	August 2009	Initial issue
1.0.2	September 2009	Added information about the support of the printer driver in section C.4
1.0.3	December 2009	1. Modified the operating modes in section 2.5 2. Added the requirements of the ViewPAC SDK in section 4.3.
1.0.4	February 2010	1. Modified the specification of the Dual Battery Backup SRAM features in section 1.1. 2. Modified information about Operating Environment in section 1.2.