

分類/Classification	<input type="checkbox"/> tDS	<input type="checkbox"/> tGW	<input type="checkbox"/> PETL/tET/tPET	<input checked="" type="checkbox"/> DS/PDS/PPDS	<input type="checkbox"/> tM-752N
	<input type="checkbox"/> I/O Card	<input type="checkbox"/> VXC Card	<input type="checkbox"/> VxComm	<input type="checkbox"/> Other	
作者/Author	Tammy	日期/Date	-	編號/NO.	FAQ-008

## Q: Can I search or connect to PDS when my PC's IP address is not in the IP filter list of PDS? How can I solve it?

A. No, you cannot search or connect to PDS when the PC's IP address is not in the IP filter list of PDS. You can solve the problem by:

1. Add your PC's IP address into the IP filter table of PDS by using console command "IPFILTER" in section 9.4.1 of the PDS-700 user manual.
2. Or change your PC's IP address to one of the IP addresses listed in IP filter table.
3. Or disable the IP filter function of the PDS by using console command. Refer to "section 9.4.1 IPFILTER" of the PDS-700 user manual.

Or clear all configuration setting on PDS by using "config=RESET" command on "section 9.4.22 CONFIG" of the PDS-700 user manual. It also clears the IP filter table, password, alias... setting. You have to reboot the PDS for loading new configuration.